
User's Guide

Microsoft® Mouse

**(Serial Version)
for the IBM® Personal Computer**

Installation and Operation Manual

Microsoft Corporation

Information in this document is subject to change without notice and does not represent a commitment on the part of Microsoft Corporation. The software described in this document is furnished under a license agreement or nondisclosure agreement. The software may be used or copied only in accordance with the terms of the agreement. It is against the law to copy any part of the software on cassette tape, disk, or any other medium for any purpose other than the purchaser's personal use.

©Microsoft Corporation, 1984

If you have questions about this documentation or enclosed software, complete the Problem Report at the back of this manual and return it to Microsoft.

Microsoft and the Microsoft logo are registered trademarks of Microsoft Corporation.

IBM is a registered trademark of International Business Machines Corporation.

Document No. 8809-300-02p
Part No. 039-099-027

Microsoft Mouse (Serial Version) Addendum

Version 3.0 of the mouse driver software (the version included in this package) and later versions will run correctly if you are using an IBM Color Graphics Adapter, IBM Monochrome Adapter, Hercules Graphics Card, IBM Enhanced Graphics Adapter, or IBM All Points Addressable Graphics Adapter.

Demonstration Programs

In this section in Chapter 3 of the Mouse Installation and Operation Manual, page 25, change the Note to the following:

Note

Piano does not run on an IBM 3270 Personal Computer with an All Points Addressable Graphics Adapter.

The Game of Life runs only on an IBM Personal Computer with a Color/Graphics Monitor Adapter or an Enhanced Graphics Adapter.

Making Mouse System Calls

In this section in Chapter 4 of the Mouse Installation and Operation Manual, page 49, change the first sentence in the first paragraph to read:

This section describes how to make mouse system calls from the BASIC interpreter, from assembly language programs, and from programs in high-level languages such as FORTRAN, Pascal, and BASIC.

Making Calls from High-Level Languages

In this section in Chapter 4 of the Mouse Installation and Operation Manual, page 52, change the first sentence in the first paragraph to read:

You can make calls from compiled FORTRAN, Pascal, and BASIC language programs.

Preface

In this section of the Microsoft Notepad Manual, page iii (unnumbered), add the following text as the last paragraph under the "Important" heading:

Notepad does not run on an IBM 3270 Personal Computer with an All Points Addressable Graphics Adapter.

What You Need

In this section in Chapter 1 of the PC Paintbrush User's Guide, page 4, add the following note after the last paragraph:

Note

PC Paintbrush does not run if you are using an IBM Monochrome Adapter or an IBM 3270 Personal Computer with an All Points Addressable Graphics Adapter.

Introduction

Add the following to the "Introduction" section on p. 9 of the PC Paintbrush User's Guide:

Do not erase files from the original Microsoft Mouse Program Disk. Before beginning the PC Paintbrush installation, make certain you are using a copy of the Program Disk. Follow these steps to erase the PBRUSH.EXE or PBRUSH1.EXE file:

1. Insert the PC Paintbrush disk into disk drive A.
2. If you are using an IBM Enhanced Graphics Adapter, type the following at the A> prompt:

erase PBRUSH.EXE

3. If you are not using an IBM Enhanced Graphics Adapter, type the following at the A> prompt:

erase PBRUSH1.EXE

Display Adapters

Add the following to p. 70 in the "Display Adapters" section of the PC Paintbrush User's Guide:

If you are using the IBM Enhanced Graphics Adapter, please note the following:

- To use PC Paintbrush with the IBM Enhanced Graphics Adapter, your disk (or directory) must include all the PC Paintbrush files plus the EGA.DEV file.
 - The See Clip option on the Page Menu is not available if you are using an IBM Enhanced Graphics Adapter with PC Paintbrush.
-

Local Undo

Add the following to p. 19 of the PC Paintbrush User's Guide:

- You can use the Backspace key to perform a Local Undo when using any tool except the Hand and Text tools. Place the cursor on the area to be undone and press the Backspace key.
 - When using the Show Screen, Adjust Palette, or ZOOM-in/zoom-in options, you can cancel an action by pressing both mouse buttons at the same time.
-

README.DOC

Please be sure to read the README.DOC file on your System Disk before installing and using the Microsoft Mouse. The README.DOC file contains information that became available after this manual was printed.


Preface

This manual explains how to use the Microsoft Mouse and accompanying software. In particular, it contains information about:

- How to install the mouse
 - How to use the mouse in programs
 - How to make system calls to the mouse software from your application programs
-

Important

This manual assumes that you have read Section 2, "Setup," and Section 3, "Operation," in the IBM Personal Computer *Guide to Operations* manual. It also assumes that you are familiar with Chapter 3, "DOS Commands," in the IBM Personal Computer *Disk Operating System* manual.



Contents

1	Introduction	1	
	Hardware Features	3	
	Software Features	4	
	Differences Between Mouse Versions	5	5
	How to Use This Manual	6	
2	Installation	7	
	Preliminary Procedures	9	
	Mouse Installation Procedure	11	
	Software Installation Procedure	12	
3	How to Use the Mouse	19	
	Basic Techniques	21	
	Demonstration Programs	25	
4	Mouse Interface and System Calls	37	
	Mouse Interface	39	
	Making Mouse System Calls	49	
	Function Descriptions	54	
	Appendix A	Cleaning Instructions	77
	Appendix B	Piano Program Listing	81
	Appendix C	Sample Cursors	91
	Index	111	

CONTENTS

1. Introduction	1
2. Theoretical Framework	5
3. Methodology	10
4. Data Collection	15
5. Results	20
6. Discussion	25
7. Conclusion	30
8. References	35
9. Appendix A	40
10. Appendix B	45
11. Appendix C	50
12. Appendix D	55
13. Appendix E	60
14. Appendix F	65
15. Appendix G	70
16. Appendix H	75
17. Appendix I	80
18. Appendix J	85
19. Appendix K	90
20. Appendix L	95
21. Appendix M	100
22. Appendix N	105
23. Appendix O	110
24. Appendix P	115
25. Appendix Q	120
26. Appendix R	125
27. Appendix S	130
28. Appendix T	135
29. Appendix U	140
30. Appendix V	145
31. Appendix W	150
32. Appendix X	155
33. Appendix Y	160
34. Appendix Z	165
35. Appendix AA	170
36. Appendix AB	175
37. Appendix AC	180
38. Appendix AD	185
39. Appendix AE	190
40. Appendix AF	195
41. Appendix AG	200
42. Appendix AH	205
43. Appendix AI	210
44. Appendix AJ	215
45. Appendix AK	220
46. Appendix AL	225
47. Appendix AM	230
48. Appendix AN	235
49. Appendix AO	240
50. Appendix AP	245
51. Appendix AQ	250
52. Appendix AR	255
53. Appendix AS	260
54. Appendix AT	265
55. Appendix AU	270
56. Appendix AV	275
57. Appendix AW	280
58. Appendix AX	285
59. Appendix AY	290
60. Appendix AZ	295
61. Appendix BA	300
62. Appendix BB	305
63. Appendix BC	310
64. Appendix BD	315
65. Appendix BE	320
66. Appendix BF	325
67. Appendix BG	330
68. Appendix BH	335
69. Appendix BI	340
70. Appendix BJ	345
71. Appendix BK	350
72. Appendix BL	355
73. Appendix BM	360
74. Appendix BN	365
75. Appendix BO	370
76. Appendix BP	375
77. Appendix BQ	380
78. Appendix BR	385
79. Appendix BS	390
80. Appendix BT	395
81. Appendix BU	400
82. Appendix BV	405
83. Appendix BW	410
84. Appendix BX	415
85. Appendix BY	420
86. Appendix BZ	425
87. Appendix CA	430
88. Appendix CB	435
89. Appendix CC	440
90. Appendix CD	445
91. Appendix CE	450
92. Appendix CF	455
93. Appendix CG	460
94. Appendix CH	465
95. Appendix CI	470
96. Appendix CJ	475
97. Appendix CK	480
98. Appendix CL	485
99. Appendix CM	490
100. Appendix CN	495
101. Appendix CO	500
102. Appendix CP	505
103. Appendix CQ	510
104. Appendix CR	515
105. Appendix CS	520
106. Appendix CT	525
107. Appendix CU	530
108. Appendix CV	535
109. Appendix CW	540
110. Appendix CX	545
111. Appendix CY	550
112. Appendix CZ	555
113. Appendix DA	560
114. Appendix DB	565
115. Appendix DC	570
116. Appendix DD	575
117. Appendix DE	580
118. Appendix DF	585
119. Appendix DG	590
120. Appendix DH	595
121. Appendix DI	600
122. Appendix DJ	605
123. Appendix DK	610
124. Appendix DL	615
125. Appendix DM	620
126. Appendix DN	625
127. Appendix DO	630
128. Appendix DP	635
129. Appendix DQ	640
130. Appendix DR	645
131. Appendix DS	650
132. Appendix DT	655
133. Appendix DU	660
134. Appendix DV	665
135. Appendix DW	670
136. Appendix DX	675
137. Appendix DY	680
138. Appendix DZ	685
139. Appendix EA	690
140. Appendix EB	695
141. Appendix EC	700
142. Appendix ED	705
143. Appendix EE	710
144. Appendix EF	715
145. Appendix EG	720
146. Appendix EH	725
147. Appendix EI	730
148. Appendix EJ	735
149. Appendix EK	740
150. Appendix EL	745
151. Appendix EM	750
152. Appendix EN	755
153. Appendix EO	760
154. Appendix EP	765
155. Appendix EQ	770
156. Appendix ER	775
157. Appendix ES	780
158. Appendix ET	785
159. Appendix EU	790
160. Appendix EV	795
161. Appendix EW	800
162. Appendix EX	805
163. Appendix EY	810
164. Appendix EZ	815
165. Appendix FA	820
166. Appendix FB	825
167. Appendix FC	830
168. Appendix FD	835
169. Appendix FE	840
170. Appendix FF	845
171. Appendix FG	850
172. Appendix FH	855
173. Appendix FI	860
174. Appendix FJ	865
175. Appendix FK	870
176. Appendix FL	875
177. Appendix FM	880
178. Appendix FN	885
179. Appendix FO	890
180. Appendix FP	895
181. Appendix FQ	900
182. Appendix FR	905
183. Appendix FS	910
184. Appendix FT	915
185. Appendix FU	920
186. Appendix FV	925
187. Appendix FW	930
188. Appendix FX	935
189. Appendix FY	940
190. Appendix FZ	945
191. Appendix GA	950
192. Appendix GB	955
193. Appendix GC	960
194. Appendix GD	965
195. Appendix GE	970
196. Appendix GF	975
197. Appendix GG	980
198. Appendix GH	985
199. Appendix GI	990
200. Appendix GJ	995
201. Appendix GK	1000
202. Appendix GL	1005
203. Appendix GM	1010
204. Appendix GN	1015
205. Appendix GO	1020
206. Appendix GP	1025
207. Appendix GQ	1030
208. Appendix GR	1035
209. Appendix GS	1040
210. Appendix GT	1045
211. Appendix GU	1050
212. Appendix GV	1055
213. Appendix GW	1060
214. Appendix GX	1065
215. Appendix GY	1070
216. Appendix GZ	1075
217. Appendix HA	1080
218. Appendix HB	1085
219. Appendix HC	1090
220. Appendix HD	1095
221. Appendix HE	1100
222. Appendix HF	1105
223. Appendix HG	1110
224. Appendix HH	1115
225. Appendix HI	1120
226. Appendix HJ	1125
227. Appendix HK	1130
228. Appendix HL	1135
229. Appendix HM	1140
230. Appendix HN	1145
231. Appendix HO	1150
232. Appendix HP	1155
233. Appendix HQ	1160
234. Appendix HR	1165
235. Appendix HS	1170
236. Appendix HT	1175
237. Appendix HU	1180
238. Appendix HV	1185
239. Appendix HW	1190
240. Appendix HX	1195
241. Appendix HY	1200
242. Appendix HZ	1205
243. Appendix IA	1210
244. Appendix IB	1215
245. Appendix IC	1220
246. Appendix ID	1225
247. Appendix IE	1230
248. Appendix IF	1235
249. Appendix IG	1240
250. Appendix IH	1245
251. Appendix II	1250
252. Appendix IJ	1255
253. Appendix IK	1260
254. Appendix IL	1265
255. Appendix IM	1270
256. Appendix IN	1275
257. Appendix IO	1280
258. Appendix IP	1285
259. Appendix IQ	1290
260. Appendix IR	1295
261. Appendix IS	1300
262. Appendix IT	1305
263. Appendix IU	1310
264. Appendix IV	1315
265. Appendix IW	1320
266. Appendix IX	1325
267. Appendix IY	1330
268. Appendix IZ	1335
269. Appendix JA	1340
270. Appendix JB	1345
271. Appendix JC	1350
272. Appendix JD	1355
273. Appendix JE	1360
274. Appendix JF	1365
275. Appendix JG	1370
276. Appendix JH	1375
277. Appendix JI	1380
278. Appendix JJ	1385
279. Appendix JK	1390
280. Appendix JL	1395
281. Appendix JM	1400
282. Appendix JN	1405
283. Appendix JO	1410
284. Appendix JP	1415
285. Appendix JQ	1420
286. Appendix JR	1425
287. Appendix JS	1430
288. Appendix JT	1435
289. Appendix JU	1440
290. Appendix JV	1445
291. Appendix JW	1450
292. Appendix JX	1455
293. Appendix JY	1460
294. Appendix JZ	1465
295. Appendix KA	1470
296. Appendix KB	1475
297. Appendix KC	1480
298. Appendix KD	1485
299. Appendix KE	1490
300. Appendix KF	1495
301. Appendix KG	1500
302. Appendix KH	1505
303. Appendix KI	1510
304. Appendix KJ	1515
305. Appendix KK	1520
306. Appendix KL	1525
307. Appendix KM	1530
308. Appendix KN	1535
309. Appendix KO	1540
310. Appendix KP	1545
311. Appendix KQ	1550
312. Appendix KR	1555
313. Appendix KS	1560
314. Appendix KT	1565
315. Appendix KU	1570
316. Appendix KV	1575
317. Appendix KW	1580
318. Appendix KX	1585
319. Appendix KY	1590
320. Appendix KZ	1595
321. Appendix LA	1600
322. Appendix LB	1605
323. Appendix LC	1610
324. Appendix LD	1615
325. Appendix LE	1620
326. Appendix LF	1625
327. Appendix LG	1630
328. Appendix LH	1635
329. Appendix LI	1640
330. Appendix LJ	1645
331. Appendix LK	1650
332. Appendix LL	1655
333. Appendix LM	1660
334. Appendix LN	1665
335. Appendix LO	1670
336. Appendix LP	1675
337. Appendix LQ	1680
338. Appendix LR	1685
339. Appendix LS	1690
340. Appendix LT	1695
341. Appendix LU	1700
342. Appendix LV	1705
343. Appendix LW	1710
344. Appendix LX	1715
345. Appendix LY	1720
346. Appendix LZ	1725
347. Appendix MA	1730
348. Appendix MB	1735
349. Appendix MC	1740
350. Appendix MD	1745
351. Appendix ME	1750
352. Appendix MF	1755
353. Appendix MG	1760
354. Appendix MH	1765
355. Appendix MI	1770
356. Appendix MJ	1775
357. Appendix MK	1780
358. Appendix ML	1785
359. Appendix MM	1790
360. Appendix MN	1795
361. Appendix MO	1800
362. Appendix MP	1805
363. Appendix MQ	1810
364. Appendix MR	1815
365. Appendix MS	1820
366. Appendix MT	1825
367. Appendix MU	1830
368. Appendix MV	1835
369. Appendix MW	1840
370. Appendix MX	1845
371. Appendix MY	1850
372. Appendix MZ	1855
373. Appendix NA	1860
374. Appendix NB	1865
375. Appendix NC	1870
376. Appendix ND	1875
377. Appendix NE	1880
378. Appendix NF	1885
379. Appendix NG	1890
380. Appendix NH	1895
381. Appendix NI	1900
382. Appendix NJ	1905
383. Appendix NK	1910
384. Appendix NL	1915
385. Appendix NM	1920
386. Appendix NN	1925
387. Appendix NO	1930
388. Appendix NP	1935
389. Appendix NQ	1940
390. Appendix NR	1945
391. Appendix NS	1950
392. Appendix NT	1955
393. Appendix NU	1960
394. Appendix NV	1965
395. Appendix NW	1970
396. Appendix NX	1975
397. Appendix NY	1980
398. Appendix NZ	1985
399. Appendix OA	1990
400. Appendix OB	1995
401. Appendix OC	2000
402. Appendix OD	2005
403. Appendix OE	2010
404. Appendix OF	2015
405. Appendix OG	2020
406. Appendix OH	2025
407. Appendix OI	2030
408. Appendix OJ	2035
409. Appendix OK	2040
410. Appendix OL	2045
411. Appendix OM	2050
412. Appendix ON	2055
413. Appendix OO	2060
414. Appendix OP	2065
415. Appendix OQ	2070
416. Appendix OR	2075
417. Appendix OS	2080
418. Appendix OT	2085
419. Appendix OU	2090
420. Appendix OV	2095
421. Appendix OW	2100
422. Appendix OX	2105
423. Appendix OY	2110
424. Appendix OZ	2115
425. Appendix PA	2120
426. Appendix PB	2125
427. Appendix PC	2130
428. Appendix PD	2135
429. Appendix PE	2140
430. Appendix PF	2145
431. Appendix PG	2150
432. Appendix PH	2155
433. Appendix PI	2160
434. Appendix PJ	2165
435. Appendix PK	2170
436. Appendix PL	2175
437. Appendix PM	2180
438. Appendix PN	2185
439. Appendix PO	2190
440. Appendix PP	2195
441. Appendix PQ	2200
442. Appendix PR	2205
443. Appendix PS	2210
444. Appendix PT	2215
445. Appendix PU	2220
446. Appendix PV	2225
447. Appendix PW	2230
448. Appendix PX	2235
449. Appendix PY	2240
450. Appendix PZ	2245
451. Appendix QA	2250
452. Appendix QB	2255
453. Appendix QC	2260
454. Appendix QD	2265
455. Appendix QE	2270
456. Appendix QF	2275
457. Appendix QG	2280
458. Appendix QH	2285
459. Appendix QI	2290
460. Appendix QJ	2295
461. Appendix QK	2300
462. Appendix QL	2305
463. Appendix QM	2310
464. Appendix QN	2315
465. Appendix QO	2320
466. Appendix QP	2325
467. Appendix QQ	2330
468. Appendix QR	2335
469. Appendix QS	2340
470. Appendix QT	2345
471. Appendix QU	2350
472. Appendix QV	2355
473. Appendix QW	2360
474. Appendix QX	2365
475. Appendix QY	2370
476. Appendix QZ	2375
477. Appendix RA	2380
478. Appendix RB	2385
479. Appendix RC	2390
480. Appendix RD	2395
481. Appendix RE	2400
482. Appendix RF	2405
483. Appendix RG	2410
484. Appendix RH	2415
485. Appendix RI	2420
486. Appendix RJ	2425
487. Appendix RK	2430
488. Appendix RL	2435
489. Appendix RM	2440
490. Appendix RN	2445
491. Appendix RO	2450
492. Appendix RP	2455
493. Appendix RQ	2460
494. Appendix RR	2465
495. Appendix RS	2470
496. Appendix RT	2475
497. Appendix RU	2480
498. Appendix RV	2485
499. Appendix RW	2490
500. Appendix RX	2495
501. Appendix RY	2500
502. Appendix RZ	2505
503. Appendix SA	2510
504. Appendix SB	2515
505. Appendix SC	2520
506. Appendix SD	2525
507. Appendix SE	2530
508. Appendix SF	2535
509. Appendix SG	2540
510. Appendix SH	2545
511. Appendix SI	2550
512. Appendix SJ	2555
513. Appendix SK	2560
514. Appendix SL	2565
515. Appendix SM	2570
516. Appendix SN	2575
517. Appendix SO	2580
518. Appendix SP	2585
519. Appendix SQ	2590
520. Appendix SR	2595
521. Appendix SS	2600
522. Appendix ST	2605
523. Appendix SU	2610
524. Appendix SV	2615
525. Appendix SW	

Chapter 1


Introduction

Hardware Features 3

Software Features 4

Differences Between Mouse Versions 5

How to Use This Manual 6



The Microsoft® Mouse is a hand-held pointing device that controls the motion of the cursor on the CRT screen of the IBM® Personal Computer. Designed to be used with a variety of screen-oriented programs, the Microsoft Mouse frees you from dependence on directional and text keys to move the cursor and to make command selections.

By sliding the Microsoft Mouse across a flat surface, you can guide the cursor to the words and symbols on the screen that represent the commands of a program. By pressing the buttons on the mouse, you can select the commands that you want to be performed. You use the mouse instead of the keyboard to direct the action of the program.

The Microsoft Mouse includes all the software and hardware necessary to use the mouse with your computer. The Microsoft Mouse is simple to use and easy to learn. This manual shows how to install the mouse and how to use it.

Hardware Features

The Microsoft Mouse hardware consists of a mouse pointing unit, attached cable, and a 25-pin "female" connector. The mouse has two buttons for flexible command selection and a removable ball for easy cleaning.

The mouse can be used with any serial communications interface board capable of RS-232 standard asynchronous data communications. The only other requirement is either a 25-pin male connector or an adapter connector for the mouse cable. All power for the mouse is supplied by your computer; no additional power is required.

Software Features

The Microsoft Mouse software consists of the driver program for implementing the mouse and demonstration programs that will help you learn how to use the mouse.

No special configuration is required to operate the mouse. Simply load the mouse software into memory and you are ready to use the mouse in any program that uses the Microsoft Mouse.

The mouse driver programs make the necessary modifications to the operating system to run the mouse. Two driver programs are provided for the different versions of DOS. The instructions on using the driver programs are given in the "Software Installation" section of Chapter 2.

The three demonstration programs, Doodle, Piano, and Life, are designed to teach you the basic techniques of the Microsoft Mouse. If you read the short tutorial in Chapter 3 and experiment with the programs, you will soon be an expert at using the mouse.

The applications software is a set of programs called Microsoft Mouse Menu. These are programs that provide mouse support and permit you to use "popup menus" and the Microsoft Mouse for application programs that currently have no built-in mouse support. Included are prewritten mouse menus for some of the most popular applications and a program to create your own mouse menus. For more information, see the *Mouse Menu* manual.

Also included in the Microsoft Mouse package are mouse functions to incorporate the Microsoft Mouse into your BASIC, assembly, and high-level language application programs. Mouse functions allow a program to access the mouse and control the cursor. You can call these functions from your application programs by using the system calls described in Chapter 4.

Differences Between Mouse Versions

There are two operational versions of the Microsoft Mouse: Bus version and Serial version. The versions differ in system requirements and the hardware included in the mouse package. The software is the same for either version.

The Serial version mouse is for the IBM PC equipped with a serial communications interface board capable of RS-232 standard asynchronous communication. The board must have a 25-pin male connector or a 25-pin male-to-female adapter. Serial version packages include the mouse pointing unit, a connecting cable, and a 25-pin female connector.

The Bus version mouse includes the mouse pointing unit, connecting cable, a 9-pin female connector, and an interface circuit board. The Bus version is for the IBM PC that either doesn't have a serial communications interface board installed or whose serial communications port is already used for something else.

How to Use This Manual


This manual provides ready information for both first-time mouse users and experienced programmers.

- Chapter 1 introduces the Microsoft Mouse hardware and software.
- Chapter 2 lists detailed instructions for installing the Microsoft Mouse on your computer.
- Chapter 3 gives the operating instructions for the Microsoft Mouse and teaches the basic techniques of the mouse with a simple tutorial.
- Chapter 4 discusses the interface between the Microsoft Mouse and your computer, and describes the mouse functions that can be called by your application programs with the mouse system calls.
- Appendix A explains how to clean the Microsoft Mouse.
- Appendix B is the BASIC program listing of the demonstration program Piano.
- Appendix C lists eight sample cursors that you may incorporate into your own application programs.

Chapter 2

Installation

Preliminary Procedures	9
System Requirements	9
Unpacking	10
Removing the Foam Ring	11
Mouse Installation Procedure	11
Software Installation Procedures	12
Manual Installation Procedure	13
Unsuccessful Installation	14
Automatic Installation Procedures	15
DOS Versions 1.x Installation Procedure	16
DOS Versions 2.x Installation Procedure	17
Backup Copies	18



This chapter gives instructions for installing the Microsoft Mouse and mouse software. Before installing the mouse, read the following preliminary procedures.

Preliminary Procedures

First, make sure that your system meets all the criteria set forth in the following "System Requirements" section. The IBM Personal Computer should be set up and operational as specified in the IBM *Guide to Operations* manual.

System Requirements

To use your Microsoft Mouse successfully, you will need the following:

1. An IBM Personal Computer
2. An IBM Personal Computer Disk Operating System (DOS), any version
3. A disk drive
4. A screen monitor
5. An interface board capable of RS-232 standard serial communications with either a 25-pin female connector or an adapter cable for connecting to the mouse 25-pin male connector
6. The Microsoft Mouse
7. The Microsoft Mouse software disk
8. A high-resolution screen graphics interface board. (The IBM Color/Graphics Adapter board is recommended.)

Unpacking

Upon receipt of your Microsoft Mouse package, check carefully for shipping damage. If any item is damaged or missing, report it to your computer dealer for further action.

Your Microsoft Mouse package should include the following:

The Microsoft Mouse

The Microsoft Mouse software disk with the following files:

123.DEF	MENU.COM	MPMS.MNU
123.MNU	MOUSE.COM	PIANO.BAS
AUTOEXEC.BAT	MOUSE.LIB	PIANO.EXE
DOODLE.EXE	MOUSE.SYS	VC.DEF
HOKUSAI	MPIBM.DEF	VC.MNU
LIFE.EXE	MPIBM.MNU	WS.DEF
MAKEMENU.EXE	MPMS.DEF	WS.MNU

Note

Because the Microsoft Mouse is packaged with other Microsoft products, there may be additional files listed on the disk, or the above files may be contained on another disk.

The Microsoft Mouse Installation and Operation Manual

A Microsoft Customer Service Plan

If reshipment of the mouse or the software disk is necessary, contact Microsoft Corporation as instructed in the Customer Service Plan before returning it.

Removing the Foam Ring

To protect the mouse during shipping, a soft foam ring is placed between the ball-retaining cover on the bottom of the mouse and the ball inside. Before installing the mouse, you will need to remove the ring. Follow these steps:

1. Hold the mouse upside down and locate the foam ring. (It should be clearly visible in the center of the mouse.)
2. Grasp the ring with your fingers.
3. Carefully pull the ring out from under the retaining cover and free the ring from the mouse.

If you have trouble, follow the procedure in Appendix A, "Cleaning Instructions," to remove the ball-retaining cover. Then remove the ring and replace the ball-retaining cover as instructed.

Mouse Installation Procedure

Use the following procedure to connect the Microsoft Mouse to a serial communications port.

Note

Once you connect the mouse to the selected serial port and run the mouse software, the port can only be used for mouse input. That is, the mouse software modifies DOS so that the port is no longer available for application programs or languages such as BASIC. To change ports, you must move the mouse cable and change the software as described in the "Software Installation Procedures" section of this chapter.

Microsoft Mouse

1. Set the power switch to OFF unless the system unit is already off.
2. Locate a serial communications port on the back of the system unit. See the IBM *Guide to Operations* manual to determine how the ports are numbered.
3. Connect the mouse cable to the serial port connector.

Note

Some computer or serial interface boards may have a different type of connector. If this is the case, ask your computer dealer or the computer manufacturer how to obtain an adapter cable.

The mouse should now be installed. The next step is installing the software. The following section will tell you how.

Software Installation Procedures

This section gives instructions for loading the Microsoft Mouse software into the IBM PC memory. The software can be loaded manually after each system reset or automatically from a system disk. The following subsections describe the ways to load the mouse software.

Using a system disk for automatic installation is the most convenient way to load the mouse software. It requires a few preliminary steps to copy the appropriate mouse files onto each system disk you plan to use. When you complete these steps, you will not have to load the mouse software after each system reset.

Manual Installation

Use the following procedure if you wish to install the mouse software manually each time you load the Disk Operating System (DOS). The DOS is loaded after you turn on the computer and after a system reset (pressing the DEL key while holding down the CTRL and ALT keys).

1. Insert your system disk into drive A and turn on the power to the computer, or if power is already on, perform a system reset. When the computer has finished its self-test, it will ask you to change the time and date. After providing the needed information or just pressing the RETURN key, you will see the DOS banner and the A> prompt.
2. If you have a multiple drive system, insert the mouse disk into drive B. Type,

B:

and press the RETURN key.

If you have a single drive system, remove the system disk from drive A and insert the mouse disk.

3. If the mouse is connected to the first serial port, type,

MOUSE /1

and press the RETURN key. If the mouse is connected to the second serial port, type,

MOUSE /2

and press the RETURN key.

The computer responds by running the MOUSE.COM program to load the mouse software into memory. If successful, the screen will display the message:

Mouse driver installed

You can now use the Microsoft Mouse. Remember that when loading the mouse software manually, steps 2 and 3 should be repeated after each system reset.

Unsuccessful Installation

If the software installation was unsuccessful, the screen will display one of two messages. If the screen displays,

Bad command or filename

it indicates that the MOUSE.COM program is either missing or cannot be run. To prevent this problem, make sure MOUSE.COM is on the disk you are using. Also make sure you are installing the mouse software from the active disk drive. Then, repeat steps 2 and 3. If you receive the message again, the problem is possibly a damaged disk.

If the mouse is improperly installed or there are other hardware problems related to the serial port, the screen will display:

Mouse: Serial card not found

If you receive this message, check to see that the serial communications interface board is correctly installed and working. See the board's technical manual for instructions on testing the interface board. If the board is not functioning properly, contact your computer dealer for help.

Automatic Installation

Automatic installation permits you to bypass the steps required to load the mouse software manually. Automatic installation consists of a system disk containing the DOS and a special file that directs the computer to load the mouse software each time the operating system is loaded into memory.

Creating a system disk for automatic installation of the mouse software consists of the following three steps:

1. Copy the appropriate mouse files onto each system disk you plan to use with the mouse.
2. Add the appropriate command line to either of the following: AUTOEXEC.BAT file (DOS versions 1.x) or CONFIG.SYS file (DOS versions 2.x).
3. Test the system disk by performing a system reset.

The following procedures show how to add the mouse software to system disks. Use the procedure that is appropriate for your DOS version. If necessary, refer to the operating system manual for help with the utilities used in this procedure.

DOS Versions 1.x Installation Procedure

1. Insert the desired system disk into drive A. You will use this disk to automatically install the mouse software when DOS is loaded into memory.
2. Turn on the power to the computer, or if the power is already on, perform a system reset. When the computer has completed its self-test, enter the time and date (or just press the RETURN key for each prompt) until you see the A> prompt.
3. Insert the mouse disk into drive B. If you have a single-drive system, remove the system disk and insert the mouse disk into drive A. Follow the instructions on the screen for changing disks. If you are unsure as to how to copy files with a single-drive system, see the *IBM DOS* manual for instructions.
4. Copy the MOUSE.COM file onto the system disk.

Note

If you don't have an AUTOEXEC.BAT file on your system disk, copy AUTOEXEC.BAT from the mouse disk to your system disk.

5. Remove the mouse disk from drive B and load a word processing program or text editor into memory.
6. If the mouse is connected to the first serial port, use a word processing program or text editor to insert the following command line into the AUTOEXEC.BAT file:

MOUSE /1

If the mouse is connected to the second serial port, substitute MOUSE /2 for MOUSE /1.

7. Repeat Steps 1 through 6 for each system disk that you plan to use with the mouse.
8. Test the AUTOEXEC.BAT file by performing a system reset. If the mouse software is loaded successfully, you will see the message:

Mouse driver installed

If unsuccessful, check the AUTOEXEC.BAT file for errors and try the procedure again. If unsuccessful again, see "Unsuccessful Installation" in the preceding section.

You now have a system disk that will automatically install the mouse software each time you load the operating system.

DOS Versions 2.x Installation Procedure

1. Insert the desired DOS 2.x system disk into drive A. You will use this disk to automatically install the mouse software when DOS is loaded into memory.
2. Turn on the power to the computer, or if the power is already on, perform a system reset. When the computer has completed its self-test, enter the time and date (or just press the RETURN key for each prompt) until you see the A> prompt.
3. Insert the mouse disk into drive B. If you have a single drive system, remove the system disk and insert the mouse disk into drive A. Follow the instructions on the screen for changing disks. If you are unsure as to how to copy files with a single drive system, see the *IBM DOS* manual for instructions.
4. Copy the MOUSE.SYS file onto the system disk.
5. Remove the mouse software disk from drive B and load a word processing program or text editor into memory.

6. If the mouse is connected to the first serial port, use the word processing program or text editor to insert the following command line into the CONFIG.SYS file:

DEVICE = MOUSE.SYS /1

If the mouse is connected to the second serial port, substitute MOUSE.SYS /2 for MOUSE.SYS /1.

7. Repeat the steps 1 through 6 for each system disk that you want to use with the mouse.
8. Test the CONFIG.SYS file by performing a system reset. If the mouse software is loaded successfully, you will see the message:

Mouse driver installed

If unsuccessful, check the CONFIG.SYS file for errors, and repeat the procedure. If unsuccessful again, see "Unsuccessful Installation" in the preceding section.

You now have a system disk that will automatically install the mouse software each time you load the operating system.

Backup Copies

It is always good practice to make a backup copy of a disk. If you do not have a copy of the Microsoft Mouse disk, use the following procedure to make a backup copy of the disk:

1. Use the FORMAT program to format a new disk.
2. Use the DISKCOPY program to copy the files on the mouse disk to the new disk.
3. Label the new disk "Microsoft Mouse."

To use the FORMAT and DISKCOPY programs, follow the instructions in the IBM *Disk Operating System* manual.

Store the original mouse disk in a cool, dry place away from direct sunlight.

Chapter 3

How to Use the Mouse

Basic Techniques 21

 Mouse Anatomy 21

 Mouse Surface Requirements 22

 Holding the Mouse 23

 Moving the Mouse/Controlling the Cursor 23

Demonstration Programs 25

 Program 1: Piano 26

 Program 2: The Game of Life 29

 Placing and Removing Cells on the Grid 30

 The Commands 31

 Selecting and Entering Commands 32

 Playing the Game 34



In this chapter, you will learn the basic techniques of using the mouse, and practice these techniques using two demonstration programs, Piano and The Game of Life.

Basic Techniques

The Microsoft Mouse takes just a few minutes to learn. If you have never used a mouse, the following sections will help you get acquainted. If you have used a mouse before, these sections will indicate differences between the Microsoft Mouse and other mouse devices.

Mouse Anatomy

Before using the Microsoft Mouse, it is a good idea to examine its working parts. Using Figure 3.1, locate the left and right buttons. The buttons permit you to make selections when presented with choices by a program. When you press and release a button, the mouse passes this information to the program.




Figure 3.1 Mouse Ball and Buttons

A button's function depends on how the current program has defined it. Just like the programmable keys on a keyboard, the function of a button can change from program to program.

Again using Figure 3.1, turn the mouse upside down and locate the ball. The ball controls the movement of the cursor on the screen. When you hold the mouse top side up and slide it across a hard, flat surface, the ball rolls within its socket. The mouse translates this rolling into directional data and passes it to the mouse software to move the cursor on the screen.

The Microsoft Mouse is enclosed in a tough and durable plastic case. Although it can survive a fall from a desk top, take care to safeguard against falls and other accidents that might shorten its operating life.

Mouse Surface Requirements

Use the mouse on any hard, flat surface, such as a desk. We recommend placing the mouse right beside the keyboard since most programs that use the Microsoft Mouse combine both the mouse and the keyboard for input. But any configuration which is comfortable for you and any surface which is hard and flat is fine.

The mouse depends on free movement in all directions, so make sure that there is adequate space for uninterrupted movement of the mouse and your arm. For most programs, a clear space of ten by ten inches is fine.

For best performance, make sure that the surface is free of dirt and lint. The mouse requires good contact between the ball and the surface to work well. Also, do not use the mouse on sticky or wet surfaces. A sticky surface can cause buildup on the ball and prevent it from rolling freely in its socket. A wet surface can lead to a short in the internal circuitry, damaging the mouse.

Note that some accumulation of dirt and lint in the mouse is unavoidable and can impair mouse performance. You can remove an accumulation of dirt by cleaning the mouse. See Appendix A, "Cleaning Instructions."

Holding the Mouse

The Microsoft Mouse is designed to be easily held in either the right or the left hand. To hold the mouse:


1. Place your palm over the Microsoft logo on the mouse body.
2. Hold your index and middle fingers over the buttons.
3. Grip the mouse with your thumb and free fingers.

Grip the mouse tightly enough to be able to lift it off the surface. Your index and middle fingers should be relaxed but ready to press the buttons.

Moving the Mouse/Controlling the Cursor

The Microsoft Mouse controls the motion of the cursor when a program that uses the mouse is running. The shape of the cursor and its starting point on the screen depend on the program, but the way the cursor moves on the screen is the same for all programs.

To move the cursor, simply move the mouse in the direction that you wish the cursor to move. All motions of the cursor are relative to the front of the mouse (where the buttons are located). Pushing the mouse to the front moves the cursor to the top of the screen. Pulling in the opposite direction moves the cursor to the bottom of the screen. Unlike the direction keys on the keyboard, the mouse permits you to move the cursor in any direction, even diagonally. Figure 3.2 illustrates ways that you can move the mouse and the corresponding cursor motions.



Movement of
cursor on screen
corresponds to
movement of
mouse on table
or desk




Figure 3.2 Mouse and Cursor Motions

The cursor moves only when the mouse moves across the surface. The location of the mouse on the surface is immaterial. This means that you can lift the mouse off the surface and return it to its starting point without returning the cursor to its starting point. This feature is useful when you are moving the cursor all the way across the screen. The move can be an accumulation of short strokes instead of one long stroke.

Demonstration Programs

The three demonstration programs, Doodle, Piano, and The Game of Life, are designed to let you practice and master the basic techniques of the Microsoft Mouse. Piano and Life are explained in the following sections.

Doodle is a graphics demonstration program for sketching different shapes on your computer screen. A special file (HOKUSAI) has been included on the mouse software disk to show what can be created with Doodle. For instructions on how to use Doodle, see the Doodle manual which is part of the Microsoft Mouse package.

To load a demonstration program, type the filename at the keyboard and press the RETURN key. The filenames of these programs are:

DOODLE
PIANO
LIFE

Remember, if the Microsoft Mouse software disk is not in the default drive, you must precede the filename with a drive name.

Note

The Game of Life runs only on an IBM Personal Computer that has a Color/Graphics Monitor Adapter.

When the program is loaded and execution has begun, you will see the game screen and the mouse cursor. We recommend trying Piano first to learn how to move and control the cursor. Then try The Game of Life to learn how to use the Microsoft Mouse to select commands in a program.

Program 1: Piano

Piano lets you play music at a video keyboard. The game screen consists of a keyboard (21 white keys and 15 black keys) and a “quit” box in the lower right corner.




Figure 3.3 Piano Screen

The cursor is in the middle of the screen just below the keyboard. Practice moving the cursor by moving the mouse from side to side. Notice how just a small motion of the mouse moves the cursor quickly and accurately. With just a little practice you can pinpoint even the smallest objects on the screen.

Don't be afraid to move the cursor to the edge of the screen. The screen edge forms a boundary beyond which the cursor will not pass.

The notes of the white keys range from low C on the left to high B on the right. The black keys are the sharps and flats between these notes. To play a note, use the mouse to move the cursor over the key that you want and press the left button. Note that the tip of the cursor must be within the boundaries of the key.

For example, to play middle C move the cursor to the eighth white key from the left and press the left button.




Figure 3.4 Playing the Piano

The computer responds by playing a middle C. The note plays as long as you hold the button down and stops as soon as you release the button.

Play another note by moving the cursor to another key and pressing the left button. Each note you choose plays as long as you hold the button down. If you move the cursor off the keyboard and press the button, no note will play.

Moving the cursor to a key and pressing the button is a method of selection. Many programs use this method to allow you to choose a program action from a menu of commands. You simply move the cursor to the word, command, or symbol that represents the action and press the button. This method is faster and easier than typing command letters or names at the keyboard.

Now return the cursor to middle C. To play an octave higher, you can either move eight white keys to the right, or leave the cursor where it is and press the mouse's right button. In Piano, the right button always plays a note one octave higher than the current note.

Choosing to press one button instead of another is a method of selecting options within a given action—in this case, choosing to play the octave above instead of the note itself. Many programs use this method to permit you to select between options in a command.

Starting at low C (the white key on the far left), press the left button and hold it down while you move the cursor across the keyboard. As the cursor moves from one key to the next, the notes change instantly and you hear a rapid series of notes. Try the right button, too.

Holding a button down while you move the cursor is a method of extending an action across the screen—in this case, extending the action “play” from one key to the next. Many programs use this method to allow you to mark the range of a specific action. For example, if the action is drawing a line, you can mark the starting point, the line's path, and its ending point.

When you have finished playing Piano, move the cursor to the quit box and press the left button. The computer responds by leaving Piano and displaying the system prompt.

Program 2: The Game of Life

The Game of Life lets you simulate the growth and death of cultures of living cells. The game consists of a 20- by 39-line grid, a command line, and a message line.




Figure 3.5 Life Screen

The object of the game is to place cells in the squares of the grid and watch how they interact generation after generation.

The Game of Life has three simple rules:

1. Survival. Every cell with two or three adjacent neighbors (vertically, horizontally, or diagonally) survives for the next generation.
2. Birth. Each empty square adjacent to exactly three live cells is a birth square. A new cell appears there in the next generation.
3. Death. Each cell with four or more neighbors dies from overpopulation. Each cell that has one or zero neighbors dies from isolation. Any cell that dies leaves an empty square in the next generation.

As simple as these rules are, the game presents a surprising complexity in the interactions of the cells. In many cases, the cells pass through several different patterns before settling down to stable or oscillating patterns, or disappearing completely from the screen. In a few cases, the cells grow indefinitely, sometimes gliding across the screen, sometimes making an infinite number of replicas of themselves.

Placing and Removing Cells on the Grid

Each square in the grid represents the space in which one cell can live. At the beginning of the game, the grid is blank. To place a cell in a square, touch the tip of the cursor to the square and press the left button. (In The Game of Life the right button has no effect.)




Figure 3.6 Placing a Cell

If you want to place many cells in the grid at once, move the cursor across the grid while holding down the left button. Be sure to start with the cursor in an empty cell. Cells will continue to be placed in the grid until you release the button.

Cells can only live and grow within the boundaries of the grid. If you try to place a cell outside of the grid, a warning tone sounds.

If you want to remove a cell from a square, touch the tip of the cursor to the cell and press the left button. To remove many cells at once, move the cursor over cells in the grid while holding down the left button. Be sure to start with the cursor in a square that has a cell. Cells will continue to be removed until you release the button.

The Commands

The Game of Life has five commands that control the action of the game. Each command has a command word that appears in the command menu below the grid.

The Blank command removes all cells from the grid and resets the generation count to zero. Use the Blank command whenever you want to start a new cell culture.

The Go command starts the game, giving life to the cells you have placed in the grid. When you select Go, the grid changes to reflect the survivals, births, and deaths of the first generation of cells, then the second, and so on through each successive generation. As the grid changes, the message line keeps a count of the number of generations that have passed. The generations continue (even if no cells remain) until you stop Life by selecting the Halt command.

The Halt command stops the game after you have started it with a Go command. When you select Halt, all action on the screen stops and the message line tells you the number of the generation now on the screen. After the Halt command, you may use Go to continue Life, Step to continue one more generation of Life, or Blank to clear the grid. You can also place or remove cells from the grid.

The Step command starts the game like the Go command but sustains it for one generation only. When you select Step, the grid changes to reflect the survivals, births, and deaths of one generation and then all action stops. The message line displays the number of the generation now on the screen.

The Quit command ends the game. When you select Quit, the message "Enter Y to confirm" appears in the message line. Type Y to end The Game of Life; press the CANCEL (ESC) key to continue.

Selecting and Entering Commands

There are three ways to select and enter commands:

1. Move the cursor to the word in the command menu and press and release the left button on the mouse,
2. Type the command letter (first letter of the command word), or
3. Use the space bar or TAB key to move the menu highlight to the command word and then press the RETURN key.

The most convenient method is to move the cursor to the word in the command menu and press and release the left button.

To practice this method, select the Go command. After placing cells in the grid, move the cursor so that its tip touches the word "Go" in the command menu, then press the left button. Be careful to touch the tip to the word; if it does not touch you will get a warning tone.




Figure 3.7 Selecting the Go Command

To stop the action, use the cursor to select the Halt command.


Try selecting the Go command using another method. The effect is the same, but you might find that using the keyboard is cumbersome compared to using the mouse.

Playing the Game

The Game of Life is a game of discovery. Since in most cases the outcome is unpredictable, a large part of the charm of the game is discovering just what a certain pattern will do.


When playing the Game of Life for the first time, we recommend that you start small—with three cells—and combine them in as many patterns as possible before moving on to more cells. In this way, you will discover the basic patterns that develop into stable (unchanging), oscillating, and disappearing cultures.

The Game of Life was first suggested in 1970 by John Conway. It quickly became a popular simulation game for computers. Since that time, many patterns have been discovered that give interesting results. The illustrations on the following pages show some of these patterns so that you may try them yourself. For descriptions of more patterns and for a discussion of the mathematics of The Game of Life, see “Mathematical Games” by M. Gardner, *Scientific American*, Vol. 223, October 1970, p.120 and “Mathematical Games” by M. Gardner, *Scientific American*, Vol. 224, February 1971, p. 112.



Block Tub Beehive Snake Saw Barge

Figure 3.8 Stable Patterns



Blinker Tumbler Figure 8 Clock

Figure 3.9 Oscillating Patterns




Figure 3.10 Glider and Space Ships




Figure 3.11 Patterns with Interesting Lives

Chapter 4

Mouse Interface and System Calls

Mouse Interface	39
The Screen Modes	40
The Virtual Screen	41
The Graphics and Text Cursors	42
The Graphics Cursor	43
The Graphics Cursor “Hot Spot”	44
The Software Text Cursor	45
The Hardware Text Cursor	46
The Buttons	47
The Mouse Unit of Distance: The Mickey	47
The Internal Cursor Flag	48
Making Mouse System Calls	49
Making Calls From the BASIC Interpreter	49
Making Calls From Assembly Language Programs	51
Making Calls From High-Level Languages	52
Sample Program	53

Function Descriptions 54

- 0: Mouse Installed Flag and Reset 56
- 1: Show Cursor 57
- 2: Hide Cursor 58
- 3: Get Mouse Position and Button Status 59
- 4: Set Mouse Cursor Position 60
- 5: Get Button Press Information 61
- 6: Get Button Release Information 62
- 7: Set Minimum and
Maximum Horizontal Position 63
- 8: Set Minimum and
Maximum Vertical Position 64
- 9: Set Graphics Cursor Block 65
- 10: Set Text Cursor 67
- 11: Read Mouse Motion Counters 68
- 12: Set User-Defined
Subroutine Input Mask 69
- 13: Light Pen Emulation Mode On 71
- 14: Light Pen Emulation Mode Off 72
- 15: Set Mickey/Pixel Ratio 73
- 16: Conditional Off 74
- 19: Set Double Speed Threshold 75

This chapter provides the information you need to incorporate the Microsoft Mouse into your application programs. It describes:

The interface between your computer's screen and Microsoft Mouse software.

The steps required to make mouse system calls from BASIC, assembly, and high-level language programs.

The input, output, and operation of the mouse function system calls.

A sample BASIC program illustrating the use of the mouse functions.

Mouse system calls are easy to incorporate in new and existing application programs. To make full use of the system calls, we recommend that you carefully read each section and pay close attention to the sample program described in Appendix B of this manual.

Mouse Interface

This section describes the interface between the mouse software and the IBM Personal Computer. In particular, it describes how the mouse software uses the resources of the personal computer to create a cursor on the screen and control its movement. This section defines:

1. The screen modes
2. The virtual screen
3. The graphics and text cursors
4. The buttons
5. The mouse unit of distance: the mickey
6. The internal cursor flag

Since many of the mouse functions make use of the interface, it is important that you understand it before using the functions. Read the following sections carefully before trying to use the functions in your application programs.

The Screen Modes

The mouse software works with all four screen modes of the IBM Personal Computer. The screen modes define the number of pixels (points of light) on the screen and the types of objects you can see on the screen. The screen modes are:

1. High-resolution graphics mode
2. Four-color graphics mode
3. 80-column text mode
4. 40-column text mode

In high-resolution graphics mode, there are 128,000 pixels on the screen, each capable of being either white or black. You can control the color of each individual pixel; that is, you can change the color of a pixel without affecting its neighbors. This allows you to create any image on the screen that you want.

In four-color (medium resolution) graphics mode, there are only 64,000 pixels on the screen. Each pixel can be individually controlled, and each is capable of being one of four colors. This allows you to create images with color.

In 80-column text mode, the screen is divided into 25 lines of text characters, with 80 characters in each line. Although there are 128,000 pixels on the screen, the pixels cannot be individually controlled, as in the graphics modes. The only way to change the screen is by changing the characters on the screen. Note that each 8- by 8-pixel group forms a single character.

In 40-column text mode, the screen is divided into 25 lines of text characters, with 40 characters in each line. There are 64,000 pixels on the screen, and the pixels cannot be individually controlled. To change the screen you must change the characters on the screen. In this mode, each 16- by 8-pixel group forms a single character.

The screen modes available on your IBM Personal Computer depend on your adapter. If your computer has the Color/Graphics Monitor Adapter, all four screen modes are available. If you have the Monochrome Display and Printer Adapter, only the 40- and 80-column text modes are available.

The Virtual Screen

The mouse software operates on the IBM Personal Computer screen as if it were a "virtual screen" of 128,000 individual points arranged in a matrix of 640 horizontal by 200 vertical points. Whenever it refers to the location of an object on the screen (for example, a pixel or a character), no matter what the mode, it gives that object's location as a pair of coordinates on the virtual screen. For example, a pixel in the upper left corner of the screen has the coordinates (0,0) and a character at the center of the screen has the coordinates (320,100). Each pair of coordinates defines a point on the virtual screen. The horizontal coordinate is given first.

In high-resolution graphics mode each point in the virtual screen has a one-to-one correspondence with each pixel on the screen. In this mode, the full range of coordinates, from (0,0) to (639,199), is permitted.

In four-color graphics mode, there are half the number of pixels on the screen as in high-resolution graphics mode. To compensate, the mouse software uses even-numbered horizontal coordinates only. This means every other point in the virtual screen corresponds to a pixel.

In 80-column text mode, only characters are permitted on the screen. There are still 128,000 pixels on the screen, each corresponding one-to-one with the points in the virtual screen, but because the individual pixels in a character cannot be accessed, the mouse software uses just one pair of coordinates to refer to the location of a character. The coordinates used are the coordinates of the pixel in the upper left corner of the character. For example, the character in the upper left corner of the screen has the coordinates (0,0), the next character horizontally has the coordinates (8,0), and so on. Since each character in this mode is an 8- by 8-pixel group, both the horizontal and vertical coordinates are multiples of eight.

In 40-column text mode, the mouse software again uses the coordinates of just one pixel in a character to refer to the location of the character. But there are half the number of pixels as in 80-column text mode. To compensate, the mouse software uses horizontal coordinates that are multiples of sixteen. For example, the character in the upper left corner of the screen still has the coordinates (0,0), but the character next to it has the coordinates (16,0).

There are many mouse functions that take coordinates as input or return coordinates as output. Whenever you make a reference to a pixel or character in a function, make sure that the horizontal and vertical coordinates are correct values for the given screen mode. If you supply an incorrect value, the function will round the value down before continuing. The mouse functions always return correct values for the given screen mode.

The Graphics and Text Cursors

The mouse has three different cursors: a graphics cursor, and two text cursors. The graphics cursor is a shape (for example, an arrow) that moves over the images on the screen. The software text cursor is a character attribute (for example, an underscore) that moves from character to character on the screen. The hardware text cursor is a flashing block, half-block, or underscore that also moves from character to character on the screen. Only one cursor can be on the screen at any given time. You can choose which cursor is on the screen, and even switch back and forth between cursors.

Functions 9 and 10 of the mouse system calls permit you to define the characteristics of these cursors. You may define the characteristics yourself, or use the characteristics of the sample cursors listed in Appendix C. The following subsections describe the cursors in detail.

The Graphics Cursor

The graphics cursor is the cursor used when the IBM Personal Computer is in high-resolution or four-color graphics mode. The graphics cursor is a block of pixels. In high-resolution graphics mode, it is 256 pixels in a 16- by 16-pixel square. In four-color graphics mode, it is 128 pixels in an 8- by 16-pixel square. As you move the mouse, the block moves over the screen and interacts with the pixels directly under it. This interaction creates the cursor shape and background.

The interaction between the cursor points and screen pixels is defined by two 16- by 16-bit arrays called the screen mask and the cursor mask. In high-resolution mode, each bit in a mask corresponds to one pixel in the cursor block. In four-color graphics mode, each pair of bits corresponds to a pixel. The screen mask determines whether the cursor pixel is part of the shape or background. The cursor mask determines how the pixel under the cursor contributes to the color of the cursor.

To create the cursor, the mouse software operates on the data in the IBM Personal Computer's screen memory that defines the color of each pixel on the screen. First, the software logically ANDs the screen mask with the 256 bits of data that define the pixels under the cursor. Then, it logically XORs the cursor mask with the result of the AND operation. Table 4.1 shows how these operations affect the individual screen bits.

Table 4.1
Mask Bit Values and Screen Result

if the screen mask bit is:	if the cursor mask bit is:	the resulting screen bit is:
0	0	0
0	1	1
1	0	unchanged
1	1	inverted

In high-resolution mode, each screen bit defines the color of a single pixel, so just one bit in the screen mask and one bit in the cursor mask define the pixel's color when the cursor is over it. For example, if the first bit in the screen mask is 1 and the first bit in the cursor mask is 0, then the upper left corner of the cursor block is transparent.

In four-color graphics mode, each pair of screen bits defines the color of a pixel, so a pair of bits in the screen mask and a pair in the cursor mask define a pixel's color.

You can define the screen mask and the cursor mask values explicitly by defining the masks as arrays in your program and passing them as parameters in a call to Function 9 of the mouse system calls. By assigning the appropriate values to the screen mask and cursor mask, you can define any shape to the cursor that you wish. For an example, see the description of Function 9 later in this chapter or the sample program in Appendix B.

The Graphics Cursor "Hot Spot"

Whenever a mouse function refers to the graphics cursor location, it gives the point on the virtual screen that lies directly under the cursor's "hot spot." The hot spot is the point in the cursor block that the mouse software uses to determine the cursor coordinates.

You can define which point in the cursor block will be the hot spot by passing the horizontal and vertical coordinates of the point to Function 9. In both high-resolution and four-color graphics mode, the coordinates must be within the range -16 to 16, but in four-color graphics mode, the horizontal coordinate must be an even number. In both cases, the coordinates are relative to the upper left corner of the cursor block.


The Software Text Cursor

The software text cursor is the cursor used when the IBM Personal Computer is in 40- or 80-column text mode. The text cursor affects the appearance of the characters on the screen. Unlike the graphics cursor, the text cursor usually does not have a shape of its own; instead, it changes character attributes such as foreground and background color, intensity, and underscoring of the character directly under it. If the cursor does have a shape of its own, it is one of the 256 ASCII characters in the IBM Personal Computer character set.

The effect of the text cursor on the character under it is defined by two 16-bit values called the screen mask and the cursor mask. The screen mask determines which attributes of the character on the screen are to be preserved. The cursor mask determines how these attributes are to be altered to yield the cursor.

To create the cursor, the mouse software operates on the data that defines each character on the screen. The software first logically ANDs the screen mask and the 16 bits of screen data for the character under the cursor. It then logically XORs the cursor mask and the result of the AND operation.

In both 40-column and 80-column text modes, the 16 bits of screen data for each character take the following form:



where:

- b sets blinking or nonblinking character
- bckgd sets the background color
- i sets high intensity or medium intensity
- foregd sets the foreground color
- char is the ASCII value of the character

The range of values for each field depends on the display adapter in your computer. See the IBM *Technical Reference* manual for details.

The screen and cursor masks are divided into the same fields as shown above, so the value of these fields in the screen and cursor masks defines the new attributes of the character when the cursor is over it. For example, to invert the foreground and background colors, the screen mask and cursor mask should have the following values:

	b	bckgd	i	foregd	char	=
screen mask	0	111	0	111	11111111	&H77FF
cursor mask	0	111	0	111	00000000	&H7700

You can define the values of the screen mask and cursor mask by passing their values as parameters in Function 10 of the mouse system calls. For an example, see the description of Function 10 later in this chapter.

Whenever a mouse function refers to the text cursor location, it gives the coordinates of the character under the cursor. The text cursor does not have a hot spot.

The Hardware Text Cursor

The hardware text cursor is another cursor that can be used when the IBM Personal Computer is in text mode.

The hardware text cursor is actually the IBM Personal Computer's own cursor (the one you see after the A> prompt on the screen). The mouse software allows you to adapt this cursor for your own use.

The hardware cursor is 8 pixels wide and 8 to 12 pixels tall. Each horizontal set of pixels forms a line, called a "scan line." There are 8 to 12 scan lines. A scan line can be on or off. If a line is on, it appears as a flashing bar on the screen. If a line is off, it has no effect on the screen. You may turn on any number of adjacent scan lines. Gaps between scan lines are not allowed. This gives the hardware text cursor a characteristic box or underscore shape.

You can define which lines are on and which are off by passing the number of the first and last lines in the cursor to Function 10 of the mouse system calls. The number of lines in the hardware cursor depends on the display adapter in your IBM Personal Computer. If your computer has a Color/Graphics Monitor Adapter, the cursor has 8 lines. If your computer has a Monochrome Display and Printer Adapter, the cursor has 12 lines. The lines are numbered from 0 to 7 or from 0 to 11.

The Buttons

The mouse functions read the state of the buttons on the mouse and keep a count of the number of times the buttons are pressed and released.

A button state is “pressed” if the button is down, and “released” if the button is up. When a function returns the state of the buttons, it returns an integer value in which the first 2 bits are set or cleared. Bit 0 represents the state of the left button, and bit 1 represents the state of the right button. If a bit is set (equal to 1), the button is down. If a bit is clear (equal to 0), the button is up.

The mouse software has internal counters to keep track of the number of presses and releases of a button. The software increments a counter each time the corresponding button is pressed or released. The software sets a counter to zero after a reset (Function 0) or after a counter’s contents are read (Functions 5 and 6).

The Mouse Unit of Distance: The Mickey

The motion of the mouse is translated into values that express the direction and duration of the motion. The values are given in a unit of distance called a “mickey,” which is approximately 1/100 of an inch.

When you slide the mouse across a desk top, the mouse hardware passes the software a horizontal and a vertical “mickey count,” i.e., the number of mickeys the mouse ball has rolled in the horizontal and vertical directions. The software uses the mickey count to move the cursor a certain number of pixels on the screen.

The number of pixels moved does not have to correspond one-to-one with the number of mickeys the ball rolled. The mouse software defines a "sensitivity" for the mouse, which is a ratio of the number of mickeys required to move the cursor 8 pixels on the screen. The sensitivity determines the rate the cursor moves on the screen.

You can define the sensitivity of the mouse by passing a mickey count to Function 15 of the mouse system calls. The count can be any value from 1 to 32767. For example, if you send a count of 8, the sensitivity is 8 mickeys per 8 pixels. That is, the cursor will move 1 pixel for each mickey the ball rolls, or one character for every 8 mickeys the ball rolls.

The Internal Cursor Flag

The mouse software maintains an internal flag that determines when the cursor should be displayed on the screen. When the flag is zero, the cursor is displayed. When the flag is any other value, the cursor is hidden.

The flag is not directly accessible to your program. To change the flag's value, you must use Functions 1 and 2 in the mouse system calls. Function 1 increments the flag; Function 2 decrements it. You may use Function 0 to reset the flag to -1. The flag is also reset to -1 when you change screen modes.

Initially, the flag's value is -1, so a call to Function 1 will cause the cursor to be displayed. You can call either function any number of times, but remember each call to one function requires a subsequent call to the other to restore the flag's previous value. For example, if the cursor is on the screen and you make five calls to Function 2, you will have to make five calls to Function 1 to get the cursor back on the screen.

Making Mouse System Calls

This section describes how to make mouse system calls from the BASIC interpreter, from assembly language programs, and from programs in high-level languages such as COBOL, FORTRAN, Pascal, and BASIC. The statements and/or instructions required to make the calls depend on the language of your application program.

You can also let the mouse software call a subroutine in your program whenever a specific condition occurs. When this capability is enabled, the mouse software interrupts whatever process is going on and passes execution control to the subroutine that you have specified in Function 12 of the mouse system calls. For details, see the description of Function 12.

Making Calls From the BASIC Interpreter

To make a mouse system call from a BASIC program running under the BASIC interpreter, you must:

1. Assign the offset and segment address of the mouse software to a pair of integer variables in your program. The mouse entry offset and segment address are in memory. To get these values, insert the following statements into your program:

```

10 DEF SEG=0
20 MSEG =256*PEEK(51*4+3)+PEEK(51*4+2)
30 MOUSE=256*PEEK(51*4+1)+PEEK(51*4)+2
40 IF MSEG OR (MOUSE-2) THEN 60
50 PRINT "Mouse Driver not found": END
60 DEF SEG=MSEG
    
```

Be sure that the statements appear before any calls to mouse functions.

2. Use the CALL statement to make the call. The statement should have the form

```
CALL MOUSE(M1%, M2%, M3%, M4%)
```

where MOUSE is the variable containing the entry offset of the mouse software, and M1%, M2%, M3%, and M4% are the names of the integer variables you have chosen for parameters in this call. All four parameters must appear in the CALL statement even if no value is assigned to one or more of them. These must be integer variables. Constants and noninteger variables are not allowed.

To ensure that the variables are integer variables, use the percent sign (%) as the variable name. You may also use the DEFINT statement at the beginning of your program. For example, the statement

```
10 DEFINT A-Z
```

defines all variables as integer. With this statement at the beginning of the program, the percent sign is optional.

Example

Assuming that the variable MOUSE has the mouse software offset, use the following statements to set the cursor position to 320 (horizontal) and 100 (vertical):

```
100 '
200 ' Set cursor position to (320,100)
300 '
400 M1% = 4      ' function number is 4
500 M3% = 320    ' horizontal coordinate
600 M4% = 100    ' vertical coordinate
700 CALL MOUSE(M1%, M2%, M3%, M4%)
```

Making Calls From Assembly Language Programs

To make mouse system calls from an assembly language program, you must:

1. Load the AX, BX, CX, and DX registers with the parameter values.
2. Execute software interrupt 51 (33H).

The AX, BX, CX, and DX registers correspond to the M1%, M2%, M3%, and M4% parameters defined for the BASIC program. Values returned by the mouse functions will be placed in the registers.

Example

Use the following instructions to set the cursor position to 320 (horizontal) and 100 (vertical):

```
.*
;*
;* Set Cursor to Location (320,100)
.*
MOV  AX,  4          ;function #4
MOV  CX,  320        ;set horizontal to 320
MOV  DX,  100        ;set vertical to 100
INT  51              ;interrupt to mouse
```

This call has the same effect as the call from the BASIC program shown in the previous example.

Note

When making a mouse system call in assembly language, Functions 9 and 12 expect a somewhat different value for the fourth parameter than when calling from a BASIC program. See the description of these functions for details.

Making Calls From High-Level Languages

You can make calls from compiled COBOL, FORTRAN, Pascal, and BASIC language programs. The call is included as an ordinary procedure call in the source program. After the program is compiled, it must then be linked with the MOUSE.LIB file on the Microsoft Mouse software disk.

To make a mouse system call from a high-level language, you must:

1. Declare MOUSE or MOUSES as an external procedure. Both procedures expect to be passed the addresses (not the values) of four integer arguments, so be sure to include an appropriate parameter list in the declarations.
2. Use the normal calling conventions to make the calls. Use the procedure MOUSE if the argument addresses are in the same segment as the mouse software (short addresses), and use MOUSES if the arguments are in another segment (long addresses). If your program is in FORTRAN, use MOUSES.
3. Link the compiled program with the mouse library file MOUSE.LIB provided on the Microsoft Mouse software disk.

Example

In a Pascal program with long argument addresses, use the following statement to declare MOUSES as an external procedure:

```
PROCEDURE MOUSES  
  (VARS M1,M2,M3,M4:INTEGER);  
  EXTRN;
```

Once the procedure has been declared, use the following statements to set the cursor position to 320 (horizontal) and 100 (vertical):

```
M1 := 4      (* Function number is 4 *)
M3 := 320    (* Horizontal position *)
M4 := 100    (* Vertical position *)
MOUSES(M1, M2, M3, M4)
```

The call has the same effect as the calls from the BASIC and assembly language programs shown in the previous examples.

Sample Program

To help you learn how to use the mouse system calls, Appendix B contains the listing of the Piano demonstration program described in Chapter 3. We recommend that you read the listing and refer to this chapter for details on the operation of each function.

The Piano program listing is also in the file PIANO.BAS on the Microsoft Mouse software disk. To see how this program runs under the BASIC interpreter, start the interpreter, load PIANO.BAS, and run it.

Function Descriptions

This section defines the following mouse functions in detail.

Number	Function
0	Mouse Installed Flag and Reset
1	Show Cursor
2	Hide Cursor
3	Get Mouse Position and Button Status
4	Set Mouse Cursor Position
5	Get Button Press Information
6	Get Button Release Information
7	Set Minimum and Maximum Horizontal Position
8	Set Minimum and Maximum Vertical Position
9	Set Graphics Cursor Block
10	Set Text Cursor
11	Read Mouse Motion Counters
12	Set User-Defined Subroutine Input Mask
13	Light Pen Emulation Mode On
14	Light Pen Emulation Mode Off
15	Set Mickey/Pixel Ratio
16	Conditional Off
19	Set Double Speed Threshold

Each description specifies the parameters required to make the call (input) and the expected return values (output), any special considerations to be taken, and an example illustrating how to use the call. All examples show BASIC program segments.

In the function descriptions, the parameter names M1%, M2%, M3%, and M4% are dummy variable names. When making a call, use the names of the variables that you want to pass.

The dummy variable names include the percent sign (%) to emphasize that only integer variables can be used as parameters. Constants, single precision variables, and double precision variables are not allowed.

If the function description does not specify an input for a parameter, you need not supply a value before making the call. If the function description does not specify an output value for a parameter, the parameter's value before and after the call remains unchanged.

Caution

The mouse software does not check input values, so be sure that the values you assign to the parameters before making a call are correct for the given screen mode. If you assign incorrect values, you will get unpredictable results.

Function 0: Mouse Installed Flag and Reset

Input	Output
M1% = 0	M1% = mouse status
	M2% = number of buttons (always 2)

Returns the current status of the mouse hardware and software.

The mouse status is 0 (false) if the mouse hardware and software are not installed, and is -1 (true) if the hardware and software are installed.

The function also resets the mouse driver to the following default parameters:

Function	Parameter
cursor position	screen center
internal cursor flag	-1
graphics cursor shape/hot spot	arrow/(-1,-1)
text cursor	inverting box
user-defined call mask	all zeroes
light pen emulation mode	enabled
mickey to pixel ratio (horizontal)	8 to 8
mickey to pixel ratio (vertical)	16 to 8
min/max cursor position (horizontal)	0/639
min/max cursor position (vertical)	0/199

Example

To ensure that mouse hardware/software is installed and to reset to default values:

```
000 '
100 ' Is Mouse present? If not, error.
200 '
300 M1%=0
400 CALL MOUSE(M1%,M2%,M3%,M4%)
500 IF NOT(M1%) THEN PRINT "Mouse not installed." : END
```

Function 1: Show Cursor

Input	Output
-------	--------

M1% = 1	--
---------	----

Increments the internal cursor flag and, if the flag is 0, displays the cursor on the screen. The cursor tracks the motion of the mouse, changing position as the mouse changes position.

The current value of the internal cursor flag depends on the number of calls that have been made to Function 1 and Function 2. (See the section in this chapter, "The Internal Cursor Flag.") The default flag value is -1, so, after a reset, a call to Function 1 will display the cursor.

Example

```

100 '
200 ' Show the cursor.
300 '
400 M1% = 1
500 CALL MOUSE(M1%, M2%, M3%, M4%)
    
```


Function 2: Hide Cursor

Input	Output
-------	--------

M1% = 2	--
---------	----

Removes the cursor from the screen and decrements the internal cursor flag. The cursor, even though hidden, still tracks the motion of the mouse, changing position as the mouse changes position.

Use this function before modifying any portion of the screen containing the cursor. This prevents the cursor from possibly affecting the data written to the screen.

Remember that each call to this function decrements the internal cursor flag. Each call to this function will require a subsequent call to Function 1 to restore the flag to its previous value. (See the section in this chapter, "The Internal Cursor Flag.")

Example

```
100 '
200 ' Hide the cursor
300 '
400 M1% = 2
500 CALL MOUSE(M1%, M2%, M3%, M4%)
```

Function 3: Get Mouse Position and Button Status

Input	Output
M1% = 3	M2% = button status
	M3% = cursor position (horizontal)
	M4% = cursor position (vertical)

Returns the state of the left and right buttons and the horizontal and vertical positions of the cursor. The button status is a single integer value. Bits 0 and 1 represent the left and right buttons, respectively. A bit is 1 if a button is down, and 0 if up.

The cursor positions are always within the range of minimum and maximum values of the virtual screen. (See the section in this chapter, "The Virtual Screen.")

Example

```

100 '
200 ' Get current cursor positions, check button status.
300 '
400 M1% = 3
500 CALL MOUSE(M1%, M2%, M3%, M4%)
600 IF M2% AND 1 THEN PRINT "Left button down."
700 IF M2% AND 2 THEN PRINT "Right button down."

```

Function 4: Set Mouse Cursor Position

Input	Output
M1% = 4	--
M3% = (horizontal) new cursor position	
M4% = (vertical) new cursor position	

Sets the cursor to the specified horizontal and vertical screen positions. The new values must be in the horizontal and vertical ranges of the virtual screen. If the screen is not in high resolution mode, the values are rounded to the nearest horizontal or vertical values permitted for the current screen mode. (See the section in this chapter, "The Virtual Screen.")

Example

Assume that HMAX and VMAX contain the maximum horizontal and vertical positions values for the virtual screen. To set the cursor to the center of the screen:

```

100 '
200 ' Put cursor in center of screen
300 '
400 M1% = 4
500 M3% = INT( HMAX/2 )
600 M4% = INT( VMAX/2 )
700 CALL MOUSE(M1%,M2%,M3%,M4%)
    
```

Function 5: Get Button Press Information

Input	Output
M1% = 5	M1% = button status
M2% = button	M2% = count of button presses
	M3% = cursor (horizontal) at last press
	M4% = cursor (vertical) at last press

Returns current button status, a count of button presses since the last call to this function, and the horizontal and vertical position of the cursor at the last press of the button.

The parameter M2% specifies which button is checked. If set to 0, the left button is checked. If 1, the right button is checked.

The button status is a single integer value. Bits 0 and 1 represent the left and right buttons, respectively. A bit is 1 if a button is down, and 0 if up.

The count of button presses is always in the range 0 to 32767; overflow is not detected. The count is set to 0 after the call.

The horizontal and vertical values are in the ranges defined by the virtual screen. Note that these values represent the cursor position when the button was last pressed and do not represent the cursor's current position.

Example

```

100 '
200 ' Get cursor position at last button press.
300 '
400 M1% = 5
500 M2% = 0 ' left button
600 CALL MOUSE(M1%, M2%, M3%, M4%)
700 IF (M1% AND 1) THEN PRINT "Left button down."
```

Function 6: Get Button Release Information

Input	Output
M1% = 6	M1% = button status
M2% = button	M2% = count of button releases
	M3% = cursor (horizontal) at last release
	M4% = cursor (vertical) at last release

Returns current button status, a count of button releases since the last call to this function, and the horizontal and vertical position of the cursor at the last release of the button.

The parameter M2% specifies which button is checked. If set to 0, the left button is checked. If set to 1, the right button is checked.

The button status is a single integer value. Bits 0 and 1 represent the left and right buttons, respectively. A bit is 1 if a button is down, and 0 if up.

The count of button releases is always in the range 0 to 32767; overflow is not detected. The count is set to zero after the call.

The horizontal and vertical values are in the ranges defined by the virtual screen. Note that these values represent the cursor position when the button was last released and do not represent the cursor's current position.

Example

```

100 '
200 ' Get cursor position at last button release.
300 '
400 M1% = 6
500 M2% = 1 ' right button
600 CALL MOUSE(M1%, M2%, M3%, M4%)
700 IF (M1% AND 2) THEN PRINT "Right button down."
```

Function 7: Set Minimum and Maximum Horizontal Position

Input	Output
M1% = 7	--
M3% = minimum position	
M4% = maximum position	

Sets the minimum and maximum horizontal cursor positions on the screen. Subsequent cursor motion is restricted to the specified area. The minimum and maximum values are defined by the virtual screen. (See the section in this chapter, "The Virtual Screen.")

If the cursor is outside the area when the call is made, it moves to just inside the area. If the minimum value is greater than the maximum, the two values are swapped.

Example

```

100 '
200 ' Limit cursor to horizontal positions below 150
300 '
400 M1% = 7
500 M3% = 0
600 M4% = 150
700 CALL MOUSE(M1%, M2%, M3%, M4%)

```

Function 8: Set Minimum and Maximum Vertical Position

Input	Output
M1% = 8	--
M3% = minimum position	
M4% = maximum position	

Sets the minimum and maximum vertical cursor positions on the screen. Subsequent cursor motion is restricted to the specified area. The minimum and maximum values are defined by the virtual screen. (See the section in this chapter, "The Virtual Screen.")

If the cursor is outside the area when the call is made, it moves to just inside the area. If the minimum value is greater than the maximum, the two values are swapped.

Example

```
100 '
200 ' Limit cursor to vertical positions between 100
300 ' and 150
400 '
500 M1% = 8
600 M3% = 100
700 M4% = 150
800 CALL MOUSE(M1%, M2%, M3%, M4%)
```

Function 9: Set Graphics Cursor Block

Input

M1% = 9
M2% = cursor hot spot (horizontal)
M3% = cursor hot spot (vertical)
M4% = pointer to screen and cursor masks

Output

--

Defines the shape, color, and center of the cursor when in graphics mode.

The function uses the values found in the screen mask and cursor mask to build the cursor shape and color. (See the section in this chapter, "The Graphics Cursor.") To pass the screen mask and cursor mask in BASIC, assign their values to an integer array and use the first element of the array as the fourth parameter in the call (see example). To pass the screen and cursor masks in assembly language, assign their values to two contiguous arrays and pass the address of the first array in register DX. Be sure to load the segment address of the arrays in the ES register before making the call.

The cursor hot spot values must define one pixel within the cursor. (See the section in this chapter, "The Graphics Cursor Hot Spot.") The values must be within the range -16 to 16.

Example

To define a cursor in high-resolution graphics mode, first define the values to the cursor array and then make the call:

```

100 '
200 ' Define the screen mask
300 '
400 CURSOR(0,0)=&HFFFF '1111111111111111
500 CURSOR(1,0)=&HFFFF '1111111111111111
600 CURSOR(2,0)=&HFFFF '1111111111111111
700 CURSOR(3,0)=&HFFFF '1111111111111111
800 CURSOR(4,0)=&HFFFF '1111111111111111
900 CURSOR(5,0)=&HFFFF '1111111111111111
1000 CURSOR(6,0)=&HFFFF '1111111111111111
1100 CURSOR(7,0)=&HFFFF '1111111111111111
1200 CURSOR(8,0)=&HFFFF '1111111111111111
1300 CURSOR(9,0)=&HFFFF '1111111111111111
1400 CURSOR(10,0)=&HFFFF '1111111111111111
1500 CURSOR(11,0)=&HFFFF '1111111111111111
1600 CURSOR(12,0)=&HFFFF '1111111111111111
1700 CURSOR(13,0)=&HFFFF '1111111111111111
1800 CURSOR(14,0)=&HFFFF '1111111111111111
1900 CURSOR(15,0)=&HFFFF '1111111111111111
2000 '
2100 ' Define cursor mask
2200 '
2300 CURSOR(0,1)=&H8000 '1000000000000000
2400 CURSOR(1,1)=&HE000 '1110000000000000
2500 CURSOR(2,1)=&HF800 '1111100000000000
2600 CURSOR(3,1)=&HFE00 '1111111000000000
2700 CURSOR(4,1)=&HD800 '1101100000000000
2800 CURSOR(5,1)=&H0C00 '0000110000000000
2900 CURSOR(6,1)=&H0600 '0000011000000000
3000 CURSOR(7,1)=&H0300 '0000001100000000
3100 CURSOR(8,1)=&H0000 '0000000000000000
3200 CURSOR(9,1)=&H0000 '0000000000000000
3300 CURSOR(10,1)=&H0000 '0000000000000000
3400 CURSOR(11,1)=&H0000 '0000000000000000
3500 CURSOR(12,1)=&H0000 '0000000000000000
3600 CURSOR(13,1)=&H0000 '0000000000000000
3700 CURSOR(14,1)=&H0000 '0000000000000000
3800 CURSOR(15,1)=&H0000 '0000000000000000
3900 '
4000 ' Define cursor shape, color, and center
4100 '
4200 M1% = 9
4300 M2% = 0 ' Horizontal hot spot
4400 M3% = 0 ' Vertical hot spot
4500 CALL MOUSE(M1%, M2%, M3%, CURSOR(0,0))

```

Function 10: Set Text Cursor

Input	Output
M1% = 10	--
M2% = cursor select	
M3% = screen mask value/scan line start	
M4% = cursor mask value/scan line stop	

Selects the software or hardware text cursor. If the software text cursor is selected, this function defines the character attributes of the cursor when in text mode. If the hardware text cursor is selected, this function defines the first and last scan lines to be shown on the screen.

The value of the parameter M2% selects the cursor type. If the value is 0, the software text cursor is selected. If the value is 1, the hardware text cursor is selected.

If the software text cursor is selected, the parameters M3% and M4% must specify the screen and cursor masks. These masks define the attributes of a character when the cursor is over it. (See the section in this chapter, "The Software Text Cursor.") The mask values depend on the display adapter in your computer.

If the hardware cursor is selected, the parameters M3% and M4% must contain the line numbers of the first and last scan line in the cursor to be show on the screen. (See the section in this chapter, "The Hardware Text Cursor.") The line numbers depend on the display adapter in your computer.

Example

To create a text cursor that inverts the foreground and background colors:

```

100 M1%=10
110 M2%=0          ' select text cursor
120 M3%=&HFFFF     ' screen mask
130 M4%=&H7700     ' cursor mask
140 CALL MOUSE(M1%,M2%,M3%,M4%)

```

If you have installed both a color/graphics board and a monochrome board in your computer, you can change lines 120 and 130 to read as follows:

```
120 M3%=&H77FF
130 M4%=&HEA00
```

Function 11: Read Mouse Motion Counters

Input	Output
M1% = 11	M3% = count (horizontal) M4% = count (vertical)

Returns the horizontal and vertical mickey count since the last call to this function. The mickey count is the distance in 1/100 inch increments that the mouse has moved. (See the section in this chapter, "The Mouse Unit of Distance: The Mickey.")

The mickey count is always within the range -32768 to 32767. A positive horizontal count specifies a motion to the right. A positive vertical count specifies a motion to the bottom of the screen. Overflow is ignored.

The mickey count is set to 0 after the call is completed.

Example

```
100 '
200 ' Get the mickey count
300 '
400 M1% = 11
500 CALL MOUSE(M1%, M2%, M3%, M4%)
```

Function 12: Set User-Defined Subroutine Input Mask

Input	Output
M1% = 12	--
M3% = call mask	
M4% = address offset to subroutine	

Sets the call mask and subroutine address for the mouse software interrupts. The mouse software interrupts automatically, stops execution of your program and calls the specified subroutine whenever one or more of the conditions defined by the call mask occur. On completion of the subroutine, your program will continue execution at the point of interruption.

The call mask, a single integer value, defines which conditions will cause an interrupt. Each bit in the call mask corresponds to a specific condition as shown here:

Mask bit	Condition
0	cursor position changes
1	left button pressed
2	left button released
3	right button pressed
4	right button released
5-15	not used

To enable an interrupt for a given condition, set the corresponding call mask bit to 1 and pass the mask as parameter M3%. To disable a condition, set the corresponding bit to 0 and pass the mask. All conditions are automatically disabled by Function 0.

When the mouse software makes a call to the subroutine, it loads the following information into the CPU registers:

Register	Information
AX	condition mask (similar to the call mask except a bit is set only if the condition has occurred)
BX	button state
CX	cursor position (horizontal)
DX	cursor position (vertical)

To use this function with the BASIC interpreter, load an assembly language subroutine into memory (use the same segment as the BASIC interpreter), assign the entry address of the subroutine to an integer variable, and pass this variable to Function 12 as the fourth parameter.

To use this function in assembly language, load the ES register with the subroutine's segment address, and load the DX register with the subroutine's offset.

Example

Assuming that a subroutine has been loaded into memory and that the integer variable SKETCH has been assigned the subroutine's entry address, use the following statements to set up calls on any press of the left button.

```
100 '
200 ' Call subroutine SKETCH on left button press
300 '
400 M1% = 12
500 M3% = &H4000
600 M4% = SKETCH
700 CALL MOUSE(M1%, M2%, M3%, M4%)
```

Function 13: Light Pen Emulation Mode On

Input	Output
-------	--------

M1% = 13	--
----------	----

Enables the light pen emulation by the mouse. When the mouse emulates the light pen, calls to the PEN function, described in the IBM *BASIC* manual, will return the cursor position at the last "pen down."

"Pen down" and "pen off the screen" are controlled by the mouse buttons. The pen is down when both buttons are down. The pen is off the screen when both buttons are up.

The mouse software enables light pen emulation mode after each reset (Function 0).

Example

```

100 '
200 ' Enable Light Pen
300 '
400 M1% = 13
500 CALL MOUSE(M1%, M2%, M3%, M4%)
    
```

Function 14: Light Pen Emulation Mode Off

Input	Output
-------	--------

M1% = 14	--
----------	----

Disables the light pen emulation. When light pen emulation is disabled, calls to the PEN function, described in the IBM *BASIC* manual, return information about the light pen only.

Example

```
100 '
200 '   Disable Light Pen
300 '
400 M1% = 14
500 CALL MOUSE(M1%, M2%, M3%, M4%)
```

Function 15: Set Mickey/Pixel Ratio

Input	Output
M1% = 15	--
M3% = mickey/pixel ratio (horizontal)	
M4% = mickey/pixel ratio (vertical)	

Sets the mickey to pixel ratio for mouse motion. (See the section in this chapter, "The Mouse Unit of Distance: The Mickey.") The horizontal and vertical ratios specify a number of mickeys per 8 pixels. The values must be in the range 1 to 32767.

The default value for the horizontal ratio is 8 mickeys to 8 pixels. The default value for the vertical ratio is 16 mickeys to 8 pixels. In the default setting, it takes 6.4 inches of mouse travel to move the cursor across the screen horizontally, and 4.0 inches of travel to move it vertically.

Example

```

100  '
200  ' Set mickey/pixel ratio at 16 to 8 and 32 to 8
300  '
400  M1% = 15
500  M3% = 16      ' horizontal ratio
600  M4% = 32      ' vertical ratio
700  CALL MOUSE(M1%, M2%, M3%, M4%)

```


Function 16: Conditional Off

Input	Output
AX = 16	--
CX = upper x screen coordinate value	
DX = upper y screen coordinate value	
SI = lower x screen coordinate value	
DI = lower y screen coordinate value	

Function 16 defines a region on the screen for updating. If the mouse pointer is in or moves into the defined region, Function 16 hides the mouse cursor while the region is being updated. After calling Function 16, a subsequent call to Function 1 (Show Cursor) is needed to show the cursor again.

The region is defined by placing the screen coordinate values in the four parameter registers. The CX and DX registers define the upper left corner of the region while the SI and DI registers define the lower right corner.

Function 16 is similar to Function 2 (Hide Cursor) but is for advanced applications that require quicker screen updates. Because of the number of parameters required, Function 16 can only be used in assembly language routines. To use this function from high-level language programs, see the language reference manual on how to call assembly language routines.

Example

```

;Define screen region for conditional off
;
MOV     AX,    16    ;Load Function 16
MOV     CX,    10    ;Define upper x value of region
MOV     DX,    30    ;Define upper y value of region
MOV     DI,    40    ;Define lower y value of region
MOV     SI,    80    ;Define lower x value of region
INT     51          ;Interrupt to mouse function
;
;Screen update routine
;
MOV     AX,    1      ;Load Function 1 to show cursor
INT     51          ;Interrupt to mouse function

```

Function 19: Set Double Speed Threshold

Input

M1% = 19
M4% = Threshold speed in mickeys/second

Output

--

Function 19 sets the threshold speed for doubling the cursor's motion on the screen. Using Function 19 will make it easier to point at images widely separate on the screen.

Parameter M4% defines the threshold speed of the mouse. If no value is given, a preset value of 64 mickeys per second is assigned. If the mouse movement speed exceeds the value in M4%, cursor motion doubles in speed. The threshold speed is set until Function 19 is called again.

The speed doubling feature is not turned off in the same sense as a switch is turned off. It can be disabled by setting the value of M4% to a speed sufficiently higher than the mouse can obtain (10000 for example) and then calling Function 19.

Example

```

100  '
110  '      Set threshold to 32 mickeys/sec
120  '
130  M1% = 19
140  M4% = 32  'mickeys/seconds
150  CALL MOUSE (M1%, M2%, M3%, M4%)
.
.
1000  '      Turn off speed doubling
1010  M1% = 19
1020  M4% = 10000  'mickeys/seconds
1030  CALL MOUSE (M1%, M2%, M3%, M4%)

```



Appendix A

Cleaning Instructions

Even in the best of environments, the Microsoft Mouse will pick up dirt and lint which can build up inside the ball's socket and eventually retard mouse performance. Use the following procedure to clean the Microsoft Mouse whenever free motion of the ball is restricted. To clean the mouse, you will need a medium Phillips head screwdriver, a clean, dry cloth, and a toothpick.

1. Turn the power to your computer off.
2. Unplug the Microsoft Mouse connector from the serial port.
3. Turn the mouse upside down so that the ball is face up. See Figure A.1.




Figure A.1 Ball and Cover Fitting Screw


4. Locate the ball retaining screw. Use the Phillips screwdriver to remove the screw by turning counterclockwise (CCW). Set the screw aside in a safe place.
5. Holding your hand over the ball and retaining bracket, turn the mouse rightside up. The ball and retaining bracket should drop into your hand. If not, shake the ball loose.

Caution

Do not tap the mouse against a hard surface to loosen the ball. It may damage the internal circuitry.

6. Once the ball is free, wipe it with a clean cloth.
7. Wipe away any dirt or lint inside the socket. If any lint is clogged inside the socket, use a toothpick to loosen it. Do not use any sharp, metallic object.
8. Return the ball to its socket and place the retaining bracket over it. Insert the retaining screw and tighten.
9. Reconnect the Microsoft Mouse connector and turn power to your computer back on.

The Microsoft Mouse cleaning procedure is now complete.



Appendix B

Piano Program Listing

This appendix presents the complete source to the Piano demonstration program. The program is written in BASIC for the IBM Personal Computer's BASIC interpreter. The following is an explanation of the program details:

Line Numbers	Comments
1000-1090	Copyright message.
1100-1160	Set up music, clear graphics screen to blue.
1170-1250	Read in the frequencies for the various piano keys.
1260-1380	As explained in Chapter 4, these statements link the mouse software and the program.
1390-1430	Function 15 sets the mouse sensitivity. With this setting, a horizontal movement of 3.2 inches moves the cursor across the entire screen. This relatively high sensitivity permits songs to be played rapidly. Accuracy is no problem since the piano keys are large.
1440-1620	The integer array CURSOR contains the screen mask and the cursor mask. The masks define the shape and color of the cursor. These statements define the screen mask; the mask is set to all ones. The mask will be logically ANDed with screen under the cursor.

- 1630-1810 These statements define the cursor mask. The values will be exclusively ORed with the result of the AND operation to create the cursor shape and color. In this case, the cursor shape is a north-pointing arrowhead. Its color is the inverse of whatever is below it.
- 1820-1860 Function 9 sets the cursor shape. It also defines the cursor hot spot. In this case, the hot spot is the tip of the arrowhead. The mouse software will automatically prevent the cursor hot spot from leaving the screen.
- 1870-1930 These statements simply read in the Microsoft logo from precalculated data. The statements place the data on the screen.
- 1940-2150 These statements draw the white and black piano keys.
- 2160-2200 These statements draw the "quit" box in the lower right corner.
- 2210-2240 Function 4 centers the cursor to just under the piano keys.
- 2250 Function 1 turns the cursor on. The cursor appears on the screen and can be moved by using the mouse.

- 2260-2290 Function 3 gives the status of the two mouse buttons and the location of the cursor. This is probably the most common mouse function used in applications.
- 2300-2370 Some decision making is performed. If both mouse buttons are up, or if the mouse is not on the piano keyboard, then any sound that might be playing is turned off.
- 2380-2430 At this point, the mouse button is down over the quit box. The program turns off the mouse cursor, clears the screen, then quits.
- 2440-2510 The program has determined a button is down over the piano keyboard. These statements determine which key the mouse cursor is over.
- 2520-2570 The note is played by the SOUND statement set with the correct frequency. This note is played in the background as the program loops back to line 2090.
- 2580-2630 This data contains the correct frequency to play the musical notes.
- 2640-3050 Data to draw the Microsoft logo using the PUT statement.

```

1000 '
1010 ' THE VIRTUAL PIANO
1020 '
1030 ' COPYRIGHT (C) 1983 BY MICROSOFT CORPORATION
1040 ' WRITTEN BY CHRIS PETERS
1050 '
1060 ' -----
1070 '
1080 ' INITIALIZE
1090 '
1100 DEFINT A-Z
1110 DIM CURSOR(15,1),FREQ(27,2),MICROSOFT(839)
1120 KEY OFF
1130 PLAY"MF"
1140 SCREEN 1
1150 COLOR 1,1
1160 CLS
1170 '
1180 ' Read in the flat, normal, and sharp note frequencies
1190 '
1200 FOR J=0 TO 2
1210 FOR I=0 TO 6
1220 READ K
1230 FREQ(I,J)=K : FREQ(I+7,J)=K*2 :
      FREQ(I+14,J)=K*4 : FREQ(I+21,J)=K*8
1240 NEXT
1250 NEXT
1260 '
1270 ' Determine mouse driver location, if not found, quit.
1280 '
1290 DEF SEG=0
1300 MSEG=256*PEEK(51*4+3)+PEEK(51*4+2) 'Get mouse
                                         segment
1310 MOUSE=256*PEEK(51*4+1)+PEEK(51*4+2) 'Get mouse
                                         offset
1320 IF MSEG OR MOUSE THEN 1370
1330 PRINT"Mouse driver not found"
1340 PRINT                                'Not found
                                         so print error.
1350 PRINT"Press any key to return to system"
1360 I$=INKEY$ : IF I$="" THEN 1360 ELSE SYSTEM
1370 DEF SEG=MSEG 'Set mouse segment
1380 M1=0 : CALL MOUSE(M1,M2,M3,M4) ' Initialize the mouse
1390 '
1400 ' Set mouse sensitivity
1410 '

```

```

1420 M1 = 15 : M3=4 : M4=8
1430 CALL MOUSE(M1,M2,M3,M4)
1440 '
1450 ' Define the "logical and" cursor mask
1460 '
1470 CURSOR( 0,0)=&HFFFF ' Binary 1111111111111111
1480 CURSOR( 1,0)=&HFFFF ' Binary 1111111111111111
1490 CURSOR( 2,0)=&HFFFF ' Binary 1111111111111111
1500 CURSOR( 3,0)=&HFFFF ' Binary 1111111111111111
1510 CURSOR( 4,0)=&HFFFF ' Binary 1111111111111111
1520 CURSOR( 5,0)=&HFFFF ' Binary 1111111111111111
1530 CURSOR( 6,0)=&HFFFF ' Binary 1111111111111111
1540 CURSOR( 7,0)=&HFFFF ' Binary 1111111111111111
1550 CURSOR( 8,0)=&HFFFF ' Binary 1111111111111111
1560 CURSOR( 9,0)=&HFFFF ' Binary 1111111111111111
1570 CURSOR(10,0)=&HFFFF ' Binary 1111111111111111
1580 CURSOR(11,0)=&HFFFF ' Binary 1111111111111111
1590 CURSOR(12,0)=&HFFFF ' Binary 1111111111111111
1600 CURSOR(13,0)=&HFFFF ' Binary 1111111111111111
1610 CURSOR(14,0)=&HFFFF ' Binary 1111111111111111
1620 CURSOR(15,0)=&HFFFF ' Binary 1111111111111111
1630 '
1640 ' Define the "exclusive or" cursor mask
1650 '
1660 CURSOR( 0,1)=&H0300 ' Binary 0000001100000000
1670 CURSOR( 1,1)=&H0300 ' Binary 0000001100000000
1680 CURSOR( 2,1)=&H0FC0 ' Binary 0000111111000000
1690 CURSOR( 3,1)=&H0FC0 ' Binary 0000111111000000
1700 CURSOR( 4,1)=&H3FF0 ' Binary 0011111111110000
1710 CURSOR( 5,1)=&H3FF0 ' Binary 0011111111110000
1720 CURSOR( 6,1)=&HFCFC ' Binary 1111110011111100
1730 CURSOR( 7,1)=&HC00C ' Binary 1100000000001100
1740 CURSOR( 8,1)=&H0000 ' Binary 0000000000000000
1750 CURSOR( 9,1)=&H0000 ' Binary 0000000000000000
1760 CURSOR(10,1)=&H0000 ' Binary 0000000000000000
1770 CURSOR(11,1)=&H0000 ' Binary 0000000000000000
1780 CURSOR(12,1)=&H0000 ' Binary 0000000000000000
1790 CURSOR(13,1)=&H0000 ' Binary 0000000000000000
1800 CURSOR(14,1)=&H0000 ' Binary 0000000000000000
1810 CURSOR(15,1)=&H0000 ' Binary 0000000000000000
1820 '
1830 ' Set the mouse cursor shape
1840 '
1850 M1 = 9 : M2 = 6 : M3 = 0
1860 CALL MOUSE(M1,M2,M3,CURSOR(0,0))
1870 '
1880 ' Draw the MICROSOFT logo from pre-calculated data
1890 '

```

Microsoft Mouse

```
1900 FOR I=0 TO 779
1910 READ MICROSOFT(I)
1920 NEXT
1930 PUT(62,0),MICROSOFT,PSET
1940 '
1950 ' Initialize keyboard size parameters
1960 '
1970 YL = 60 : WKL = 80 : BKL = 45 : KW = 15 : WKN = 21
1980 XL = 320-KW*WKN : YH = YL + WKL : XH = 319 : BKW2=KW3
1990 QX = 272 : QY = 176
2000 '
2010 ' Draw the white keys
2020 '
2030 LINE (XL,YL)-(XH,YH),3,BF
2040 FOR I=XL TO XH STEP KW
2050 LINE (I,YL)-(I,YH),0
2060 NEXT
2070 '
2080 ' Draw the black keys
2090 '
2100 C=6
2110 FOR X=XL TO XH STEP KW
2120 C=C+1 : IF C=7 THEN C=0
2130 IF C=0 OR C=3 THEN 2150
2140 LINE(X-BKW2,YL)-(X+BKW2,YL+BKL),2,BF
2150 NEXT
2160 '
2170 ' Draw the quit box
2180 '
2190 LINE(QX,QY)-(319,199),3,B
2200 LOCATE 24,36 : PRINT"Quit";
2210 '
2220 ' Set mouse cursor location, then turn on cursor
2230 '
2240 M1 = 4 : M3 = 320 : M4 = 160 : CALL MOUSE(M1,M2,M3,M4)
2250 M1 = 1 : CALL MOUSE(M1,M2,M3,M4)
2260 '
2270 '     MAIN LOOP
2280 '
2290 M1=3:CALL MOUSE(M1,BT,MX,MY)      'Get mouse location
                                      and button status
2300 IF (BT AND 2) THEN OTV=7 : GOTO 2340
                                      ' If right button down, set high octave
2310 IF (BT AND 1) THEN OTV=0 : GOTO 2340
                                      ' If left button down, set lower octave
2320 SOUND 442,0 ' If both buttons up, turn off sound
2330 GOTO 2290 ' Keep looping...
2340 MX = MX2 ' Correct for medium resolution screen
```

```


2350 IF MX <= XL OR MY < YL THEN 2320 ' If above keyboard,
                                         turn off sound
2360 IF MY <= YH THEN 2470 ' If on keyboard,
                                         play sound
2370 IF MY < QY OR MX < QX THEN 2320 ' If above quit box,
                                         turn off sound
2380 '
2390 ' Button down inside the quit box
2400 '
2410 M1=2 : CALL MOUSE(M1,M2,M3,M4) ' Turn off mouse
                                         cursor
2420 CLS ' Clear screen
2430 END ' Quit
2440 '
2450 ' Button down over keyboard, determine which key
2460 '
2470 WKY = (MX-XL)KW+OTV : R = 1 ' Get which white
                                         key cursor is over
2480 IF MY > YL+BKL THEN 2560 ' Is it lower than
                                         the black keys?
2490 MK=(MX-XL) MOD KW ' No, get which
                                         side of key
2500 IF MK <= BKW2 THEN R=0 : GOTO 2560 ' Is it the left
                                         black key?
2510 IF MK >= KW-BKW2 THEN R=2 ' Is it the right
                                         black key?
2520 '
2530 ' Play the note. For BASIC interpreter duration = 2
2540 ' For BASIC compiler duration = 1
2550 '
2560 SOUND FREQ(WKY,R),2
2570 GOTO 2290 ' Continue looping
2580 '
2590 ' Musical note frequencies
2600 '
2610 DATA 131,139,156,175,185,208,233
2620 DATA 131,147,165,175,196,220,247
2630 DATA 139,156,165,185,208,233,247

```

Microsoft Mouse

[illegible]

2910 DATA -16321,768,-3073,252,0,0,1023,255,0,3840,252,0,
0,0,0,-4033,-193,1023,4095,4092
2920 DATA 240,0,0,-256,-64,4092,-1,192,-241,-16129,0,
-3841,255,0,768,1020,255,0,3840,252
2930 DATA 0,0,0,0,-4033,-193,1023,4095,4092,240,0,16128,
-64,4032,255,0,0,0,16128,252
2940 DATA -3841,255,0,768,1020,255,0,3840,252,0,0,0,0,
-4033,-241,1020,4095,1020,252,0
2950 DATA -256,-256,960,1023,252,0,0,16383,1023,-3841,
-16321,0,3840,1008,255,0,3840,252,0,0
2960 DATA 0,0,-4033,-241,1020,4095,1020,255,0,-253,-256,
960,-16129,-1,-1,-1,16380,-1,-3841,-4033
2970 DATA 0,16128,1008,255,0,3840,252,0,0,0,0,-4033,-253,
1008,4095,252,-3841,0,-961,-256
2980 DATA 192,-16129,0,0,0,3840,-1,-16129,-241,0,-253,960,
255,0,3840,252,0,0,0,0
2990 DATA -4033,-253,1008,4095,252,-193,768,-3841,-256,192,
-16129,-1009,0,-256,4032,-1,255,-253,240,-193
3000 DATA 768,255,0,3840,252,0,0,0,0,-4033,-256,960,4095,
252,-253,-1,255,-256,192,-16129
3010 DATA -253,-1,-1,768,-1,252,16128,-1,-3841,768,255,0,
3840,252,0,0,0,0,-4033,-256
3020 DATA 960,4095,252,16128,-1,240,-256,192,-16129,0,0,
0,0,-193,192,768,-1,255,768,255
3030 DATA 0,3840,252,0,0,0,0,0,0,0,0,0,768,-1,0,0,0,0,
3840,-1
3040 DATA -16129,0,0,0,0,-193,240,0,0,0,0,0,0,0,0,0,0,0
3050 DATA 0,0,0,0,0,0,0,-193,240,0,0,0,0,0,0,0,0,0



Appendix C

Sample Cursors

Standard Cursor Shape 94

Up Arrow 96

Left Arrow 98

Check Mark 100

Pointing Hand 102

Diagonal Cross 104

Rectangular Cross 106

Hourglass 108

Appendix B

Sample Program

1. The first step in the process is to identify the problem or goal that the program is intended to solve.

2. The second step is to design a solution that addresses the problem or goal.

3. The third step is to implement the solution.

4. The fourth step is to evaluate the results of the program.

5. The fifth step is to make any necessary adjustments to the program.

6. The sixth step is to document the program and its results.

7. The seventh step is to disseminate the results of the program.

8. The eighth step is to maintain the program and its results.

This appendix describes eight sample graphics cursors. These sample cursors illustrate the wide variety of cursor shapes that can be defined for use in BASIC application programs.

The sample cursors are designed for high-resolution graphics mode. Each cursor is a white shape with a black outline on a transparent field. The shape suggests the type of action you may take with the mouse. For example, an arrow usually means "make a selection by pointing at an item."

To use a sample cursor in your own BASIC program, copy the BASIC statements presented for the cursor directly to your program. Type the statements exactly as shown, using line numbers that are consistent with your program's numbering scheme.

To use a sample cursor in an assembly or high-level language program, define an array in your program and assign the values given for each cursor to the array elements. Assign the values so that their storage order is identical to their storage order in a BASIC program.

The statements in this appendix only define the cursor's shape. It is up to you to define the action associated with a cursor by including the necessary statements in your program.

Standard Cursor Shape

The standard cursor shape is a solid arrow which points up and to the left. The hot spot is just beyond the arrow's tip, so you can point to an item without covering it. The standard cursor is the most convenient shape when using the mouse to choose or select items from the screen.

```
100 '  
200 ' Define the screen mask  
300 '  
400 CURSOR( 0,0) =&H3FFF      'Binary 0011111111111111  
500 CURSOR( 1,0) =&H1FFF      'Binary 0001111111111111  
600 CURSOR( 2,0) =&H0FFF      'Binary 0000111111111111  
700 CURSOR( 3,0) =&H07FF      'Binary 0000011111111111  
800 CURSOR( 4,0) =&H03FF      'Binary 0000001111111111  
900 CURSOR( 5,0) =&H01FF      'Binary 0000000111111111  
1000 CURSOR( 6,0) =&H00FF      'Binary 0000000011111111  
1100 CURSOR( 7,0) =&H007F      'Binary 0000000001111111  
1200 CURSOR( 8,0) =&H003F      'Binary 0000000000111111  
1300 CURSOR( 9,0) =&H001F      'Binary 0000000000011111  
1400 CURSOR(10,0) =&H01FF      'Binary 0000000111111111  
1500 CURSOR(11,0) =&H10FF      'Binary 0001000011111111  
1600 CURSOR(12,0) =&H30FF      'Binary 0011000011111111  
1700 CURSOR(13,0) =&HF87F      'Binary 1111100001111111  
1800 CURSOR(14,0) =&HF87F      'Binary 1111100001111111  
1900 CURSOR(15,0) =&HFC3F      'Binary 1111110000111111
```

```

2000 '
2100 ' Define cursor mask
2200 '
2300 CURSOR( 0,1) = &H0000 'Binary 0000000000000000
2400 CURSOR( 1,1) = &H4000 'Binary 0100000000000000
2500 CURSOR( 2,1) = &H6000 'Binary 0110000000000000
2600 CURSOR( 3,1) = &H7000 'Binary 0111000000000000
2700 CURSOR( 4,1) = &H7800 'Binary 0111100000000000
2800 CURSOR( 5,1) = &H7C00 'Binary 0111110000000000
2900 CURSOR( 6,1) = &H7E00 'Binary 0111111000000000
3000 CURSOR( 7,1) = &H7F00 'Binary 0111111100000000
3100 CURSOR( 8,1) = &H7F80 'Binary 0111111110000000
3200 CURSOR( 9,1) = &H7FC0 'Binary 0111111111000000
3300 CURSOR(10,1) = &H7C00 'Binary 0111110000000000
3400 CURSOR(11,1) = &H4600 'Binary 0100011000000000
3500 CURSOR(12,1) = &H0600 'Binary 0000011000000000
3600 CURSOR(13,1) = &H0300 'Binary 0000001100000000
3700 CURSOR(14,1) = &H0300 'Binary 0000001100000000
3800 CURSOR(15,1) = &H0180 'Binary 0000000110000000
3900 '
4000 ' Define cursor shape, color, and hot spot
4100 '
4200 M1% = 9
4300 M2% = -1 ' Horizontal hot spot
4400 M3% = -1 ' Vertical hot spot
4500 CALL MOUSE(M1% , M2% , M3% , CURSOR(0,0))

```

Up Arrow

The up arrow is a solid, up-directed arrow with the hot spot at the tip. This shape is useful when directing a motion on the screen with the mouse.

```
100 '  
200 ' Define the screen mask  
300 '  
400 CURSOR( 0,0)=&HF9FF      ' Binary 1111100111111111  
500 CURSOR( 1,0)=&HF0FF      ' Binary 1111000011111111  
600 CURSOR( 2,0)=&HE07F      ' Binary 1110000001111111  
700 CURSOR( 3,0)=&HE07F      ' Binary 1110000001111111  
800 CURSOR( 4,0)=&HC03F      ' Binary 1100000000111111  
900 CURSOR( 5,0)=&HC03F      ' Binary 1100000000111111  
1000 CURSOR( 6,0)=&H801F      ' Binary 1000000000011111  
1100 CURSOR( 7,0)=&H801F      ' Binary 1000000000011111  
1200 CURSOR( 8,0)=&H000F      ' Binary 0000000000001111  
1300 CURSOR( 9,0)=&H000F      ' Binary 0000000000001111  
1400 CURSOR(10,0)=&HF0FF      ' Binary 1111000011111111  
1500 CURSOR(11,0)=&HF0FF      ' Binary 1111000011111111  
1600 CURSOR(12,0)=&HF0FF      ' Binary 1111000011111111  
1700 CURSOR(13,0)=&HF0FF      ' Binary 1111000011111111  
1800 CURSOR(14,0)=&HF0FF      ' Binary 1111000011111111  
1900 CURSOR(15,0)=&HF0FF      ' Binary 1111000011111111
```

```

2000 '
2100 ' Define the cursor mask
2200 '
2300 CURSOR( 0,1) = &H0000 ' Binary 0000000000000000
2400 CURSOR( 1,1) = &H0600 ' Binary 0000011000000000
2500 CURSOR( 2,1) = &H0F00 ' Binary 0000111100000000
2600 CURSOR( 3,1) = &H0F00 ' Binary 0000111100000000
2700 CURSOR( 4,1) = &H1F80 ' Binary 0001111110000000
2800 CURSOR( 5,1) = &H1F80 ' Binary 0001111110000000
2900 CURSOR( 6,1) = &H3FC0 ' Binary 0011111111000000
3000 CURSOR( 7,1) = &H3FC0 ' Binary 0011111111000000
3100 CURSOR( 8,1) = &H7FE0 ' Binary 0111111111100000
3200 CURSOR( 9,1) = &H0600 ' Binary 0000011000000000
3300 CURSOR(10,1) = &H0600 ' Binary 0000011000000000
3400 CURSOR(11,1) = &H0600 ' Binary 0000011000000000
3500 CURSOR(12,1) = &H0600 ' Binary 0000011000000000
3600 CURSOR(13,1) = &H0600 ' Binary 0000011000000000
3700 CURSOR(14,1) = &H0600 ' Binary 0000011000000000
3800 CURSOR(15,1) = &H0000 ' Binary 0000000000000000
3900 '
4000 ' Set the mouse cursor shape, color, and hot spot
4100 '
4200 M1 = 9
4300 M2 = 5 ' horizontal hot spot
4400 M3 = 0 ' vertical hot spot
4500 CALL MOUSE(M1,M2,M3,CURSOR(0,0))

```


Left Arrow

The left arrow is a solid, left-directed arrow with the hot spot at the tip. This shape is useful when directing a motion on the screen with the mouse. To generate a right arrow, just reverse the binary bit pattern for each array element and move the hot spot to the new tip. For example, the first element, Binary 1111111-000011111 (&HFE1F), becomes Binary 111110000111111 (&HF87F).

```

100 '
200 ' Define the screen mask
300 '
400 CURSOR( 0,0)=&HFE1F      ' Binary 1111111000011111
500 CURSOR( 1,0)=&HF01F      ' Binary 1111000000011111
600 CURSOR( 2,0)=&H0000      ' Binary 0000000000000000
700 CURSOR( 3,0)=&H0000      ' Binary 0000000000000000
800 CURSOR( 4,0)=&H0000      ' Binary 0000000000000000
900 CURSOR( 5,0)=&HF01F      ' Binary 1111000000011111
1000 CURSOR( 6,0)=&HFE1F     ' Binary 1111111000011111
1100 CURSOR( 7,0)=&HFFFF      ' Binary 1111111111111111
1200 CURSOR( 8,0)=&HFFFF      ' Binary 1111111111111111
1300 CURSOR( 9,0)=&HFFFF      ' Binary 1111111111111111
1400 CURSOR(10,0)=&HFFFF      ' Binary 1111111111111111
1500 CURSOR(11,0)=&HFFFF      ' Binary 1111111111111111
1600 CURSOR(12,0)=&HFFFF      ' Binary 1111111111111111
1700 CURSOR(13,0)=&HFFFF      ' Binary 1111111111111111
1800 CURSOR(14,0)=&HFFFF      ' Binary 1111111111111111
1900 CURSOR(15,0)=&HFFFF      ' Binary 1111111111111111

```

```

2000 '
2100 ' Define the cursor mask
2200 '
2300 CURSOR( 0,1) = &H0000 ' Binary 0000000000000000
2400 CURSOR( 1,1) = &H00C0 ' Binary 0000000011000000
2500 CURSOR( 2,1) = &H07C0 ' Binary 0000011111000000
2600 CURSOR( 3,1) = &H7FFE ' Binary 0111111111111110
2700 CURSOR( 4,1) = &H07C0 ' Binary 0000011111000000
2800 CURSOR( 5,1) = &H07C0 ' Binary 0000000011000000
2900 CURSOR( 6,1) = &H0000 ' Binary 0000000000000000
3000 CURSOR( 7,1) = &H0000 ' Binary 0000000000000000
3100 CURSOR( 8,1) = &H0000 ' Binary 0000000000000000
3200 CURSOR( 9,1) = &H0000 ' Binary 0000000000000000
3300 CURSOR(10,1) = &H0000 ' Binary 0000000000000000
3400 CURSOR(11,1) = &H0000 ' Binary 0000000000000000
3500 CURSOR(12,1) = &H0000 ' Binary 0000000000000000
3600 CURSOR(13,1) = &H0000 ' Binary 0000000000000000
3700 CURSOR(14,1) = &H0000 ' Binary 0000000000000000
3800 CURSOR(15,1) = &H0000 ' Binary 0000000000000000
3900 '
4000 ' Set the mouse cursor shape, color, and hot spot
4100 '
4200 M1 = 9
4300 M2 = 0 ' horizontal hot spot
4400 M3 = 3 ' vertical hot spot
4500 CALL MOUSE(M1,M2,M3,CURSOR(0,0))

```

Check Mark

The check mark is a solid figure with the hot spot in the center of the "V" formed by the check. The shape can be used when checking off items from a list with the mouse or while a program is checking some aspect of its operation.

```
100 '  
200 ' Define the screen mask  
300 '  
400 CURSOR( 0,0)=&HFFF0      ' Binary 1111111111110000  
500 CURSOR( 1,0)=&HFFE0      ' Binary 1111111111110000  
600 CURSOR( 2,0)=&HFFC0      ' Binary 1111111111110000  
700 CURSOR( 3,0)=&HFF81      ' Binary 1111111110000001  
800 CURSOR( 4,0)=&HFF03      ' Binary 1111111100000011  
900 CURSOR( 5,0)=&H0607      ' Binary 0000011000000111  
1000 CURSOR( 6,0)=&H000F      ' Binary 0000000000001111  
1100 CURSOR( 7,0)=&H001F      ' Binary 0000000000011111  
1200 CURSOR( 8,0)=&HC03F      ' Binary 1100000000011111  
1300 CURSOR( 9,0)=&HF07F      ' Binary 1111000001111111  
1400 CURSOR(10,0)=&HFFFF      ' Binary 1111111111111111  
1500 CURSOR(11,0)=&HFFFF      ' Binary 1111111111111111  
1600 CURSOR(12,0)=&HFFFF      ' Binary 1111111111111111  
1700 CURSOR(13,0)=&HFFFF      ' Binary 1111111111111111  
1800 CURSOR(14,0)=&HFFFF      ' Binary 1111111111111111  
1900 CURSOR(15,0)=&HFFFF      ' Binary 1111111111111111
```

```

2000 '
2100 ' Define the cursor mask
2200 '
2300 CURSOR( 0,1)=&H0000 ' Binary 0000000000000000
2400 CURSOR( 1,1)=&H0006 ' Binary 0000000000000110
2500 CURSOR( 2,1)=&H000C ' Binary 0000000000001100
2600 CURSOR( 3,1)=&H0018 ' Binary 0000000000011000
2700 CURSOR( 4,1)=&H0030 ' Binary 0000000000110000
2800 CURSOR( 5,1)=&H0060 ' Binary 0000000001100000
2900 CURSOR( 6,1)=&H70C0 ' Binary 0111000011000000
3000 CURSOR( 7,1)=&H1D80 ' Binary 0001110110000000
3100 CURSOR( 8,1)=&H0700 ' Binary 0000011100000000
3200 CURSOR( 9,1)=&H0000 ' Binary 0000000000000000
3300 CURSOR(10,1)=&H0000 ' Binary 0000000000000000
3400 CURSOR(11,1)=&H0000 ' Binary 0000000000000000
3500 CURSOR(12,1)=&H0000 ' Binary 0000000000000000
3600 CURSOR(13,1)=&H0000 ' Binary 0000000000000000
3700 CURSOR(14,1)=&H0000 ' Binary 0000000000000000
3800 CURSOR(15,1)=&H0000 ' Binary 0000000000000000
3900 '
4000 ' Set the mouse cursor shape, color, and hot spot
4100 '
4200 M1 = 9
4300 M2 = 6 ' horizontal hot spot
4400 M3 = 7 ' vertical hot spot
4500 CALL MOUSE(M1,M2,M3,CURSOR(0,0))

```

Pointing Hand

The pointing hand is a solid figure with the hot spot at the tip of the extended finger. The pointing hand is another convenient shape to use when choosing or selecting items from the screen, especially if the items are represented by icons or symbols such as the keys of a piano keyboard or a calculator.

```

100 '
200 ' Define the screen mask
300 '
400 CURSOR( 0,0)=&HE1FF      ' Binary 1110000111111111
500 CURSOR( 1,0)=&HE1FF      ' Binary 1110000111111111
600 CURSOR( 2,0)=&HE1FF      ' Binary 1110000111111111
700 CURSOR( 3,0)=&HE1FF      ' Binary 1110000111111111
800 CURSOR( 4,0)=&HE1FF      ' Binary 1110000111111111
900 CURSOR( 5,0)=&HE000      ' Binary 1110000000000000
1000 CURSOR( 6,0)=&HE000     ' Binary 1110000000000000
1100 CURSOR( 7,0)=&HE000     ' Binary 1110000000000000
1200 CURSOR( 8,0)=&H0000     ' Binary 0000000000000000
1300 CURSOR( 9,0)=&H0000     ' Binary 0000000000000000
1400 CURSOR(10,0)=&H0000     ' Binary 0000000000000000
1500 CURSOR(11,0)=&H0000     ' Binary 0000000000000000
1600 CURSOR(12,0)=&H0000     ' Binary 0000000000000000
1700 CURSOR(13,0)=&H0000     ' Binary 0000000000000000
1800 CURSOR(14,0)=&H0000     ' Binary 0000000000000000
1900 CURSOR(15,0)=&H0000     ' Binary 0000000000000000

```

```

2000 '
2100 ' Define the cursor mask
2200 '
2300 CURSOR( 0,1) =&H1E00 ' Binary 0001111000000000
2400 CURSOR( 1,1) =&H1200 ' Binary 0001001000000000
2500 CURSOR( 2,1) =&H1200 ' Binary 0001001000000000
2600 CURSOR( 3,1) =&H1200 ' Binary 0001001000000000
2700 CURSOR( 4,1) =&H1200 ' Binary 0001001000000000
2800 CURSOR( 5,1) =&H13FF ' Binary 0001001111111111
2900 CURSOR( 6,1) =&H1249 ' Binary 0001001001001001
3000 CURSOR( 7,1) =&H1249 ' Binary 0001001001001001
3100 CURSOR( 8,1) =&HF249 ' Binary 1111001001001001
3200 CURSOR( 9,1) =&H9001 ' Binary 1001000000000001
3300 CURSOR(10,1) =&H9001 ' Binary 1001000000000001
3400 CURSOR(11,1) =&H9001 ' Binary 1001000000000001
3500 CURSOR(12,1) =&H8001 ' Binary 1000000000000001
3600 CURSOR(13,1) =&H8001 ' Binary 1000000000000001
3700 CURSOR(14,1) =&H8001 ' Binary 1000000000000001
3800 CURSOR(15,1) =&HFFFF ' Binary 1111111111111111
3900 '
4000 ' Set the mouse cursor shape, color, and hot spot
4100 '
4200 M1 = 9
4300 M2 = 5 ' horizontal hot spot
4400 M3 = 0 ' vertical hot spot
4500 CALL MOUSE(M1,M2,M3,CURSOR(0,0))

```

Diagonal Cross

The diagonal cross is a solid figure with the hot spot at the center of the cross. The shape is useful as a pointer in a game, or when canceling an operation or deleting an item from a list.

```

100 '
200 ' Define the screen mask
300 '
400 CURSOR( 0,0)=&H07E0      ' Binary 0000011111100000
500 CURSOR( 1,0)=&H0180      ' Binary 0000000110000000
600 CURSOR( 2,0)=&H0000      ' Binary 0000000000000000
700 CURSOR( 3,0)=&HC003      ' Binary 1100000000000011
800 CURSOR( 4,0)=&HF00F      ' Binary 1111000000001111
900 CURSOR( 5,0)=&HC003      ' Binary 1100000000000011
1000 CURSOR( 6,0)=&H0000      ' Binary 0000000000000000
1100 CURSOR( 7,0)=&H0180      ' Binary 0000000110000000
1200 CURSOR( 8,0)=&H07E0      ' Binary 0000011111100000
1300 CURSOR( 9,0)=&HFFFF      ' Binary 1111111111111111
1400 CURSOR(10,0)=&HFFFF      ' Binary 1111111111111111
1500 CURSOR(11,0)=&HFFFF      ' Binary 1111111111111111
1600 CURSOR(12,0)=&HFFFF      ' Binary 1111111111111111
1700 CURSOR(13,0)=&HFFFF      ' Binary 1111111111111111
1800 CURSOR(14,0)=&HFFFF      ' Binary 1111111111111111
1900 CURSOR(15,0)=&HFFFF      ' Binary 1111111111111111

```

```

2000 '
2100 ' Define the cursor mask
2200 '
2300 CURSOR( 0,1) = &H0000 ' Binary 0000000000000000
2400 CURSOR( 1,1) = &H700E ' Binary 0111000000001110
2500 CURSOR( 2,1) = &H1C38 ' Binary 0001110000111000
2600 CURSOR( 3,1) = &H0660 ' Binary 0000011001100000
2700 CURSOR( 4,1) = &H03C0 ' Binary 0000001111000000
2800 CURSOR( 5,1) = &H0660 ' Binary 0000011001100000
2900 CURSOR( 6,1) = &H1C38 ' Binary 0001110000111000
3000 CURSOR( 7,1) = &H700E ' Binary 0111000000001110
3100 CURSOR( 8,1) = &H0000 ' Binary 0000000000000000
3200 CURSOR( 9,1) = &H0000 ' Binary 0000000000000000
3300 CURSOR(10,1) = &H0000 ' Binary 0000000000000000
3400 CURSOR(11,1) = &H0000 ' Binary 0000000000000000
3500 CURSOR(12,1) = &H0000 ' Binary 0000000000000000
3600 CURSOR(13,1) = &H0000 ' Binary 0000000000000000
3700 CURSOR(14,1) = &H0000 ' Binary 0000000000000000
3800 CURSOR(15,1) = &H0000 ' Binary 0000000000000000
3900 '
4000 ' Set the mouse cursor shape, color, and hot spot
4100 '
4200 M1 = 9
4300 M2 = 7 ' horizontal hot spot
4400 M3 = 4 ' vertical hot spot
4500 CALL MOUSE(M1,M2,M3,CURSOR(0,0))

```


Rectangular Cross

The rectangular cross is a solid figure with the hot spot at the center of the cross. The shape is useful as a pointer in a game, or when inserting items into a list.

```
100 '  
200 ' Define the screen mask  
300 '  
400 CURSOR( 0,0)=&HFC3F      ' Binary 1111110000111111  
500 CURSOR( 1,0)=&HFC3F      ' Binary 1111110000111111  
600 CURSOR( 2,0)=&HFC3F      ' Binary 1111110000111111  
700 CURSOR( 3,0)=&H0000      ' Binary 0000000000000000  
800 CURSOR( 4,0)=&H0000      ' Binary 0000000000000000  
900 CURSOR( 5,0)=&H0000      ' Binary 0000000000000000  
1000 CURSOR( 6,0)=&HFC3F      ' Binary 1111110000111111  
1100 CURSOR( 7,0)=&HFC3F      ' Binary 1111110000111111  
1200 CURSOR( 8,0)=&HFC3F      ' Binary 1111110000111111  
1300 CURSOR( 9,0)=&HFFFF      ' Binary 1111111111111111  
1400 CURSOR(10,0)=&HFFFF      ' Binary 1111111111111111  
1500 CURSOR(11,0)=&HFFFF      ' Binary 1111111111111111  
1600 CURSOR(12,0)=&HFFFF      ' Binary 1111111111111111  
1700 CURSOR(13,0)=&HFFFF      ' Binary 1111111111111111  
1800 CURSOR(14,0)=&HFFFF      ' Binary 1111111111111111  
1900 CURSOR(15,0)=&HFFFF      ' Binary 1111111111111111
```

```

2000 '
2100 ' Define the cursor mask
2200 '
2300 CURSOR( 0,1)=&H0000      ' Binary 0000000000000000
2400 CURSOR( 1,1)=&H0180      ' Binary 0000000110000000
2500 CURSOR( 2,1)=&H0180      ' Binary 0000000110000000
2600 CURSOR( 3,1)=&H0180      ' Binary 0000000110000000
2700 CURSOR( 4,1)=&H7FFE      ' Binary 0111111111111110
2800 CURSOR( 5,1)=&H0180      ' Binary 0000000110000000
2900 CURSOR( 6,1)=&H0180      ' Binary 0000000110000000
3000 CURSOR( 7,1)=&H0180      ' Binary 0000000110000000
3100 CURSOR( 8,1)=&H0000      ' Binary 0000000000000000
3200 CURSOR( 9,1)=&H0000      ' Binary 0000000000000000
3300 CURSOR(10,1)=&H0000      ' Binary 0000000000000000
3400 CURSOR(11,1)=&H0000      ' Binary 0000000000000000
3500 CURSOR(12,1)=&H0000      ' Binary 0000000000000000
3600 CURSOR(13,1)=&H0000      ' Binary 0000000000000000
3700 CURSOR(14,1)=&H0000      ' Binary 0000000000000000
3800 CURSOR(15,1)=&H0000      ' Binary 0000000000000000
3900 '
4000 ' Set the mouse cursor shape, color, and hot spot
4100 '
4200 M1 = 9
4300 M2 = 7 ' horizontal hot spot
4400 M3 = 4 ' vertical hot spot
4500 CALL MOUSE(M1,M2,M3,CURSOR(0,0))

```

Hourglass


The hourglass is a solid figure with the hot spot at the center of the glass. This shape can be used to show that the operation in progress will take some time to complete.

```
100 '  
200 ' Define the screen mask  
300 '  
400 '  
500 CURSOR( 1,0)=&H0000      ' Binary 0000000000000000  
600 CURSOR( 2,0)=&H0000      ' Binary 0000000000000000  
700 CURSOR( 3,0)=&H0000      ' Binary 0000000000000000  
800 CURSOR( 4,0)=&H8001      ' Binary 1000000000000001  
900 CURSOR( 5,0)=&HC003      ' Binary 1100000000000011  
1000 CURSOR( 6,0)=&HE007      ' Binary 1110000000000111  
1100 CURSOR( 7,0)=&HF00F      ' Binary 1111000000001111  
1200 CURSOR( 8,0)=&HE007      ' Binary 1110000000000111  
1300 CURSOR( 9,0)=&HC003      ' Binary 1100000000000011  
1400 CURSOR(10,0)=&H8001      ' Binary 1000000000000001  
1500 CURSOR(11,0)=&H0000      ' Binary 0000000000000000  
1600 CURSOR(12,0)=&H0000      ' Binary 0000000000000000  
1700 CURSOR(13,0)=&H0000      ' Binary 0000000000000000  
1800 CURSOR(14,0)=&H0000      ' Binary 0000000000000000  
1900 CURSOR(15,0)=&HFFFF      ' Binary 1111111111111111
```

```

2000 '
2100 ' Define the cursor mask
2200 '
2300 CURSOR( 0,1) = &H0000 ' Binary 0000000000000000
2400 CURSOR( 1,1) = &H7FFE ' Binary 0111111111111110
2500 CURSOR( 2,1) = &H6006 ' Binary 0110000000000110
2600 CURSOR( 3,1) = &H300C ' Binary 0011000000001100
2700 CURSOR( 4,1) = &H1818 ' Binary 0001100000011000
2800 CURSOR( 5,1) = &H0C30 ' Binary 0000110000110000
2900 CURSOR( 6,1) = &H0660 ' Binary 0000011001100000
3000 CURSOR( 7,1) = &H03C0 ' Binary 0000001111000000
3100 CURSOR( 8,1) = &H0660 ' Binary 0000011001100000
3200 CURSOR( 9,1) = &H0C30 ' Binary 0000110000110000
3300 CURSOR(10,1) = &H1998 ' Binary 0001100110011000
3400 CURSOR(11,1) = &H33CC ' Binary 0011001111001100
3500 CURSOR(12,1) = &H67E6 ' Binary 0110011111100110
3600 CURSOR(13,1) = &H7FFE ' Binary 0111111111111110
3700 CURSOR(14,1) = &H0000 ' Binary 0000000000000000
3800 CURSOR(15,1) = &H0000 ' Binary 0000000000000000
3900 '
4000 ' Set the mouse cursor shape, color, and hot spot
4100 '
4200 M1 = 9
4300 M2 = 7 ' horizontal hot spot
4400 M3 = 7 ' vertical hot spot
4500 CALL MOUSE(M1,M2,M3,CURSOR(0,0))

```



Index

123.DEF file, 10
123.MNU file, 10

Adapter, 9, 41, 47
Anatomy of the mouse, 21
Application programs, 4, 39
AUTOEXEC.BAT file, 10

Backup copies, 18
Ball cleaning, 22, 77-79
Basic techniques, 21-24
Bootable disk, creating, 15
Buttons
 described, 21, 47
 pressing information,
 61-62
 status, 59

Call mask, setting, 69-70
Calls from
 assembly language programs, 51
 BASIC interpreter, 49-50
 high-level language programs,
 52-53
Cleaning the mouse, 77-79

Color/graphics monitor
 adapter, 9, 41, 47
CONFIG.SYS file, 18
Coordinates, screen, 41-42
Cursor
 defining, high-resolution
 graphics mode, 43-44, 65-66
 flag, internal, 48, 57-58
 hiding, 58
 position, setting, 60
 sample, 93-109
Cursor mask
 graphics, 43, 69-70
 text, 45-47

Default values, 56
Defining integer variables, 50
Demonstration programs, 25-36
Disk
 backup, 18
 bootable, creating, 15
 storage, 18
DISKCOPY program, 18
DOODLE.EXE file, 10

Error messages, 14

Index

Foam ring, removing, 11

FORMAT program, 18

Four-color graphics mode, 43, 44

Functions

- 0, mouse installed flag and reset, 56
- 1, show cursor, 57
- 2, hide cursor, 58
- 3, get mouse position and button status, 59
- 4, set mouse cursor position, 60
- 5, get button press information, 61
- 6, get button release information, 62
- 7, set horizontal position, 63
- 8, set vertical position, 64
- 9, set graphics cursor block, 65–66
- 10, set text cursor, 67
- 11, read mouse motion counters, 68
- 12, set user-defined subroutine input mask, 69–70
- 13, light pen emulation mode on, 71
- 14, light pen emulation mode off, 72
- 15, set mickey/pixel ratio, 73
- 16, conditional off, 74
- 19, set double speed threshold, 75
- descriptions, 54
- parameters, 56

Game of Life

- commands, 31–33
- interesting patterns, 34–36
- placing, removing cells, 30–31
- rules, 30
- strategies, 34

Graphics cursor

- hot spot, 44
- mask, 43, 69–70

Graphics mode, 43–44

Hardware

- cursor, 46
- features, 3
- installation procedure, 11

High-resolution graphics mode, 43–44

HOKUSAI file, 10

Holding the mouse, 23

Inspecting the mouse, 21–22

Installation, 11–18

- automatic, 15
- backup copies, 18
- DOS versions 1.x, 16
- DOS versions 2.x, 17–18
- manual, 13
- unsuccessful, 14

Integer variables, defining, 50

Internal cursor flag, 48, 57–58

LIFE.EXE program, 10

Light pen emulation mode off, 72

on, 71

Loading procedure, 12–18

MAKEMENU.EXE file, 10

MENU.COM file, 10

Mickey, 47

Mickey/pixel ratio setting, 73

Monochrome display and printer adapter, 41, 47

Motion counter, reading, 68

Mouse package, described, 3, 10

Mouse software, interface, described, 39–48

MOUSE.COM program,
10, 14

MOUSE.LIB file, 10

MOUSE.SYS file, 10

Moving the mouse, 23-24

MPIBM.DEF file, 10

MPIBM.MNU file, 10

MPMS.DEF file, 10

MPMS.MNU file, 10

Offset, entry, 49

Package contents, 10

Piano

playing, 27-28

program listing, 81-89

PIANO.BAS file, 10

PIANO.EXE file, 10

Preliminary procedures, 9-11

README.DOC file, 10

Required tools, 77

Reshipment procedure, 10

Sample cursors, 93-109

Scan lines, 46

Screen coordinates, 41-42

Screen mask

graphics, 43-44

text, 45-47

Screen modes, 40-41

Segment address, 49

Shipping damage, 10

Software

features, 3-4

installation procedure, 12-18

values, default, 56

Surface requirements, 22

System

calls, 39

requirements, 9

Text cursor

described, 42

mask, 45-47

setting, 67

Tools, 77

VC.DEF file, 10

VC.MNU file, 10

Vertical position, setting, 64

Virtual screen, 41-42

WS.DEF file, 10

WS.MNU file, 10

